

Instructions and Advices to use the electronic controller Logik 9

ORIGINAL INSTRUCTIONS



**(INDUSTRIAL CONTROL EQUIPMENT)
39UG
FILE: E316817**

INDEX

CAUTION	Page 3
TECHNICAL FEATURES	Page 4
MOUNTING	Page 5
ELECTRICAL DRAWING AND LEGEND OF THE CONNECTIONS	Page 5
CONNECTION SERIAL NET RS485	Page 8
WARNINGS TO THE WIRING RS485	Page 8
WARNINGS TO THE WIRING OF THE CONTROLLER	Page 8
CONTROL PANEL	Page 9
DESCRIPTION OF STATUS VISUALIZATIONS	Page 11
QUICK SETTING TO START AND STOP PRESSURES	Page 11
PROGRAMMING	Page 12
ENTER PASSWORD	Page 13
MENU 1 - PPS = CHANGE PASSWORD	Page 14
MENU 2 - PP = PRESSURES	Page 14
MENU 3 - PH = TEMPERATURES	Page 14
MENU 4 - Pt = WORKING TIMER	Page 15
MENU 5 - P-F = MAINTENANCE TIMER	Page 15
MENU 6 - CnF = COMPRESSOR CONFIGURATION	Page 16
MENU 7 - HrS = WORKING HOURS	Page 18
MENU 8 - AL = ALARMS	Page 18
MENU 9 - rES = RESET	Page 19
ALARM CODES	Page 20
OPERATING PRINCIPLE	Page 21
MASTER/SLAVE OPERATION	Page 23
MULTIUNIT OPERATION	Page 24
WARRANTY	Page 25
EDITIONS LIST	Page 25

CAUTION

THE LOGIK 9 IS AN INDUSTRIAL CONTROL EQUIPMENT (NOT A SAFETY INSTRUMENT) FOR THE OPERATION OF A SCREW COMPRESSOR WITH SOFTWARE CLASS A (see EN 60730-1).

THE INSTALLATION MUST BE MADE IN ACCORDANCE TO THE LOCAL AND INTERNATIONAL STANDARDS AND REGULATIONS WHERE THE COMPRESSOR IS MANUFACTURED.

THE INSTALLATION AND START UP OF THE CONTROLLER MUST BE CARRIED OUT BY TRAINED PERSONNEL WELL KNOWN IN THIS MANUAL.

THE CONTROLLER HAS TO BE USED IN STANDARD INDUSTRIAL ENVIRONMENT AND IT CAN NOT BE USED IN EXPLOSION RISK ENVIRONMENT, MARITIME AND MILITARY PURPOSE.

THIS MANUAL COULD BE SUBJECT TO CHANGES; PLEASE CONTACT LOGIKA CONTROL TECHNICAL OFFICE IN CASE OF DOUBT ON THE LAST VERSION.

ATTENTION

LA LOGIK 9 EST UN CONTROLE EQUIPMENT INDUSTRIEL (PAS UN INSTRUMENT DE SECURITE) POUR LE FONCTIONNEMENT D'UN COMPRESSEUR A VIS AVEC SOFTWARE DE CLASS A (voir EN 60730-1).

L'INSTALLATION DOIT ETRE EFFECTUEE CONFORMEMENT AUX NORMES ET AUX REGLEMENTATIONS LOCALES ET INTERNATIONALES OU LE COMPRESSEUR EST FABRIQUE.

L'INSTALLATION ET MISE EN MARCHE DE LA COMMANDE DOIVENT ETRE EFFECTUEES PAR DU PERSONNEL QUALIFIÉ BIEN SAVOIR DANS CE MANUEL.

LE CONTROLEUR DOIT ETRE UTILISE DANS LA NORME ENVIRONNEMENT INDUSTRIEL ET IL NE PEUT PAS ETRE UTILISE DANS UN ENVIRONNEMENT DE RISQUE D'EXPLOSION ET MARITIME FINS MILITAIRES.

CE MANUEL POURRAIT ETRE SOUS RESERVE DE MODIFICATION; S'IL VOUS PLAIT CONTACTER LOGIKA CONTROL TECHNIQUE BUREAU EN CAS DE DOUTE SUR LA DERNIERE VERSION.

TECHNICAL FEATURES

- Industrial control equipment for the operation and management of screw compressors only, pollution degree 2.
- In accordance to **EC Directives**:
 Directive:
 LVD : 2014/35/UE
 EMC: 2014/30/UE
 RHOS: 2011/65/EU
 based on the following harmonized standards applied:
 SAF-EMC: EN 60730-1
 RHOS: EN 50581
- In accordance to **UL 508 (FILE #: E316817)**.
- Black auto-extinguishing box in ABS:
 - a) **according CE**: IP64 for the front panel and IP20 for the other parts;
 - b) **according UL**: type 1 and Type 12 for front panel mounting, installation in pollution degree 2 for the other parts.
- Inputs and outputs via terminal-block board to wires (250Vac – 10A – 12-24AWG) tightening torque: 8 Nm
- Working temperature: -10°C (14°F) ÷ 50°C (122°F), 90% RH (non-condensing)
- Storage temperature: -20°C (-4°F) ÷ 70°C (158°F).
- Power supply: 12 Vac ± 10% - 50÷60 Hz (power of the transformer's secondary: ~6 VA) from safety transformer
- Max. current absorbed: ~ 200mA
- Visualization through LCD custom (10 digit 7 segments + 6 icons)
 - no. 1 input for pressure transducer settable via software into input for electromechanical pressure switch
 - no. 1 input for temperature probe to detect air end temperature (KTY/NTC).
 - no. 4 key buttons: no.1 Start/Stand-by + no.3 function keys (up/down/enter)
 - no. 4 opto isolated digital inputs from 12-24Vac to detect:
 - IN 1 = emergency stop button
 - IN 2 = OR alarms and/or thermal motor – thermal fan
 - IN 3 = phases sequence relay and/or thermal motor – thermal fan
 - IN4 = remote start/stop and/or thermal motor – thermal fan
- no. 5 outputs via relay with contacts 1.5A AC1 250Vac – 6A AC1 250Vac total:
 - RL1 = line contactor
 - RL2 = star contactor
 - RL3 = delta contactor
 - RL4 = load solenoid valve
 - RL5 = settable into alarm or fan contactor
- No.1 RS485: Multiunit/Master-Slave
- Non volatile memory to keep setting data, compressor status and working hours
- The electronic controller switched OFF due to micro-interruption over ~ 300ms


Weight: ~290g

Accessories:


- nr. 1 temperature probe KTY 13.5 with black cable TPE, length 2.5 m, working range -10°C÷130°C, resolution 1°C to detect air end temperature.
- nr. 1 pressure transducer 4-20mA for working pressure control: 2 wires, AISI 316L stainless steel membrane, working range 0 ÷ 15 bar, resolution 0,1bar, precision ± 0,1bar.

MOUNTING

Use the drawing below as overall dimensions to mount the controller.



ELECTRICAL DRAWING AND LEGEND OF CONNECTIONS



NOTES ON THE ELECTRICAL CONNECTIONS

Respect the working technical features and instructions on the electrical wiring; in special way both the cables of the temperatures probes and pressure transducers must be isolated from the power cables and proper RC filters must be placed on the contactors' coils.

Besides pay attention low voltage and high voltage cables run on separate trunks.

On the back side of the controller there must be enough space for wiring and connectors.

The rear side of the controller must be protected against condensation, oil and dust.

Don't wash the front panel by water injection; clean the front panel with a soft cloth using soap water.

LEGEND**Terminal M1: Power Supply and Analog Inputs**

Poles 1-2 = power supply 12Vac \pm 15% 50÷60 Hz

Poles 3-4 = temperature probe

Poles 5-6 = pressure transducer (pole no.5 = negative - pole no.6 = positive) or free contact to the electromechanical pressure switch

Terminal M2: Outputs via Relay

Pole no.1 = common relay – 24-230Vac

Pole no.2 = output relay RL1 – line contactor

Pole no.3 = output relay RL2 – star contactor

Pole no.4 = output relay RL3 – delta contactor

Pole no.5 = output relay RL4 – load solenoid valve

Pole no.6 = output relay RL5 – alarm output or fan contactor

Terminal M3: Opto-isolated Digital Inputs

Pole no.1 = common = N

Pole no.2 = input IN 1 – emergency stop button = L

Pole no.3 = input IN 2 – OR alarms: thermal motor, thermal fan etc. = L

Pole no.4 = input IN 3 – phases sequence relay = L

Pole no.5 = input IN 4 – remote start/stop = L

NOTE: the digital inputs you do not use have to be connected directly to 12-24V otherwise they generate the related alarm

TERMINAL M4: Serial Bus RS485

Pole no.1: 0

Pole no.2: D-


Pole no.3: D+

EXAMPLE OF CONNECTION TO SECURITY PRESSURE SWITCH

Alarm related to security pressure switch **AD9**, is joined to the lacking phase to all the digital inputs. This is a shut off alarm: below you can find the connection drawing both to contactors 24Vac and/or 230Vac.


Contactors 24 Vac

If the operation of the contactors and soenoid valves come through 24 Vac, the digital inputs have to be connected to 24 Vac (see drawing on the right); on this way when the pressure switch opens due to high pressure, 24 Vac lacks and deenergize all the contactors, solenoid valve and digital: the controller detects all the digital inputs opened and signal the alarm **AD9**.



Contactors 230 Vac

If the operation of the contactors and solenoid valves comes through 230 Vac, the digital inputs have to be connected to 12 Vac; next to the contact of the pressure switch, place and energize an auxiliary relay and put the contact in serie to 12 Vac (L) (see drawing on the right). When the pressure switch is closed, the auxiliary relay with contact closed supply power to the digital inputs; the power supply of the controller is connected before the contact of the relay. When the pressure switch opens, the auxiliary relay opens power to the digital inputs; the controller detects all the digital inputs opened and signal the alarm **AD9**.




CONNECTION SERIAL NET RS485

To connect a serial net you have to pay carefully attention to some executive aspects:

- 1) Use flexible cable, shielded, twisted 22 AWG type.
- 2) Connect D- and D+ to two conductors of same couple and 0 to a third one (if available) or both conductors of a second couple; don't leave free couple of wires.
- 3) Connect the cable's shield to only one end of 0.
- 4) DO NOT CONNECT the cable's shield to the electrical ground of the plant.
- 5) The net MUST NOT BE LONGER than 400 meters.
- 6) Max connectable units through serial net RS 485 is 32.
- 7) In case of connection of more compressors via serial line RS485 you have to set the parameter **nc** into menu **EnF** (compressor setting).
- 8) The units on serial net RS485 must be connected without any reversal: pole D+ to D+, pole D- to D-, pole 0 to 0.
- 9) In case of connection with more than 2 units it is necessary to provide only one line without any deriving. At the terminal both starting and ending the net it is possible to place (in parallel to D- and D+) a termination resistance 120 Ohm.

In the picture below you can see the connection of 4 units on serial net RS485 by using a shielded cable with two twisted couples.



NOTE TO THE WIRING: wrong wiring can damage both the controller and other utilities connected on the serial net


WARNINGS TO THE WIRING RS485

- 1) The cable must be placed into a TRUNK SEPARATED by power cables and any potentially dangerous cables as lighting plant and so on.
- 2) DO NOT PLACE signal cables next to power bar, lighting lamps, antennas, transformers;
- 3) Keep signal cables FAR 2 METERS MINIMUM from units with heavy inductive (distribution cabinet, motors, inverter).
- 4) Don't pull the cables with a strength over 12 Kg; stronger strength can damage the wires and reduce the signal transmission on the line.
- 5) DO NOT: twist, knot, crush or fray the conductors.
- 6) Do not make any joints between lengths of cable: always use only one cable to connect any single unit to each others. Strip the end part carefully, do not crush the cable next to core-hitches or safety supports.
- 7) Always respect the position of the colors at the both sides of the connection.
- 8) Once the wiring is complete, visually and physically check the cables are undamaged and properly placed.

WARNINGS TO THE WIRING OF THE CONTROLLER

- 1) The connection cables temperature probe and pressure transducer must be placed in a trunk separate from the power cables.
- 2) The connections cables digital inputs must be placed in a trunk separate from the power cables.
- 3) The power cable controller must NOT be placed in the same trunk of the power cables.

CONTROL PANEL



MEANINGS OF THE GROUPS

GROUP 1

Main Visualization and in case of alarm detected: working pressure detected.

Programming: setting value.

GROUP 2

Main Visualization: unit of measurement of the pressure (bar/psi).

Programming: code of the parameter the controller is visualizing

Till Programming: joined to *Group 1* in case the controller has to visualize values expressed in thousands.

GROUP 3

Main Visualization: working temperature detected or compressor status.

Programming: code of the menu the controller is visualizing.


In case of alarm detected: code of the alarm detected.

GROUP 4

Programming: progressive number of the menu into the main flow.


MEANING OF THE ICONS

- 1.Fan working
- 2.Compressor loading - Compressor unloading (blinking)
- 3.Remote start/stop enabled
- 4.Alarm detected
- 5.Maintenance timer over
- 6.Unit of measurement of the temperature (Main Visualization)
- 7.Compressor working under Master/Slave operation



DESCRIPTION OF STATUS VISUALIZATIONS

1) Power on and the display visualizes LG9 for few seconds and then the following:



2) **OFF** status switch to **ON** by pushing  and the display visualizes the following:



3) The possible status of the compressors are the followings:

Status	Visualization		Icons
	Pressure transducer $P00=0$	Pressure switch $P00=1$	
Wait for starting (timer tOS)	Message On alternated into pressure detected	Message On blinking	
Compressor starting	Pressure detected blinking	Message run blinking	
Compressor loading	Pressure and temperature detected	Message run and temperature detected	
Compressor unloading for reaching set	Pressure and temperature detected	Message run blinking and temperature detected	 Blinking
Compressor in set	Pressure detected + Message SEt	Message SEt	
Compressor going to stop (unload running)	OFF alternated into pressure detected	OFF blinking	 in case remote start/stop input opened
Compressor stop	OFF	OFF	 in case remote start/stop input opened
Compressor shutting off due to alarm detection	SEtP + alarm code	SEtP + alarm code	

QUICK SETTING TO START AND STOP PRESSURE

On the main visualization by pushing   simultaneously you enable the quick setting to start and stop pressure; the display visualizes the following:



with start pressure value blinking; now you can change the set by  and/or  and confirm by  , so LCD shift to the following:



with stop pressure value blinking.

Follow the procedure to set the start pressure and confirm by .

Once the setting is confirmed the display shift back to the main visualization.

PROGRAMMING

When the compressor is OFF, on the main visualization you enter the main menu to the programming by pushing ; pay attention, on this way only the menu/parameters without password (level 0) are visible and settable.

You can flow up and down the flow by using  and/or ; below you can check out the menu flow with related password level to access:

NOTE: in case of alarm visualized the button  get reset function, so to enter the menu you have to reset the alarm before.

MENU	Password level	Display
1-Password	1-2	<i>PR5</i>
2-Pressures	0-1-2	<i>PP</i>
3-Temperatures	0-1-2	<i>PH</i>
4-Working timer	1-2	<i>PE</i>
5-Maintenance	0-1-2	<i>P-F</i>
6-Compressor setting	1-2	<i>CnF</i>
7-Working hours	0	<i>HrS</i>
8-Alarms	0	<i>AL</i>
9-Reset	2	<i>rES</i>


NOTE

When the last menu is visualized by pushing  you quit the flow and the display shift back to the main visualization; after 120 seconds the password level is lost.

For security reasons after 120 seconds you push any button, the controller quit the programming procedure automatically and load the setting values already modified.

ANTIPANIC FUNCTION: in any position of the flow you are by pushing  for about 5 seconds the display shift back to the main visualization.

By pushing  you confirm the menu you need to enter to set; below is an example of visualization:




- By the buttons  and/or  you select the code of the parameter to set; once the last parameter is visualized if you keep on pushing  the display shift back to the menu you are in.
- By the button  you confirm the parameter and the setting value starts blinking to indicate the editing is enabled.
- By the buttons  and/or  you change the value and confirm the new one by .

ENTER PASSWORD

When the compressor is **OFF** by pushing  for about 2 seconds you enter the label to select the password level and set the menu and parameters protected by related password code.

The display visualizes the following:



By the buttons  and/or  you can select the password level you need to enter **PA1** (Service) - **PA2** (Factory) and confirm by the button  : the display visualizes as many segments as the characters you have to enter and the first one blinks:

- select **PA1** = no. 2 segments (default password 22)
- select **PA2** = no. 3 segments (default password 333)

NOTE: without password means that the menu/parameter is visualized and editable to level 0 only.

Once the password level has been confirmed you can set the first digit by the button  and/or  and confirm by ; now the next digit starts blinking.

To set the next digits, follow the same procedure as per the first one.

The password is accepted once you confirm the last digit so you can now set the parameter related to the password level selected; in case you enter a wrong password code, the display visualizes the following message:



The message **-Err-** blinks for about 3 seconds to indicate the password code is wrong and shift back to the main visualization.

PASSWORD FORGOTTEN

In case you miss the password code, you can restore the default codes (on both 2 levels) according the following procedure:

take power off to the controller in case it is powered; then supply power again and keep on pushing  for about 5 seconds.


The display visualizes the blinking message **rES** to indicate the upload of the default password codes is in progress.

MENU 1 – *PA5* = CHANGE PASSWORD

In this menu you can change the password code related to two password levels available.

Passwords are: *PA1* (Service) - *PA2* (Factory).

To enter the menu push  and the display visualizes the following:



You can select the password level to change by using  and/or  then push  to enable the modification; in case you keep on pushing  you shift back to previous menu.

Once you enable the modification the first digits blinks so you can change it by using  and/or ; confirm the digit by  and the second one starts blinking to modification: follow the same procedure for all next digits.

Once the last digit has been confirmed, the new password code has been loaded.

MENU 2 – *PP* = PRESSURES

Below all the parameters related to the pressure.

Parameter	Description	Setting range	Default	Password
<i>P00</i>	Pressure control	0 (transducer) ÷ 1 (pressure switch)	0	1
<i>P01</i>	Top range transducer	15 ÷ 60	15 bar	2
<i>P02</i>	High pressure	(<i>P01</i> -0,5) ÷ (<i>P03</i> +0,5)	11 bar	1
<i>P03</i>	Stop pressure	(<i>P02</i> -0,5) ÷ (<i>P04</i> +0,2)	10 bar	0
<i>P04</i>	Start pressure	(<i>P03</i> -0,2) ÷ 3	8.5 bar	0
<i>P05</i>	Slave Start pressure	2,8 ÷ (<i>P04</i> -0,2)	8,3 bar	1
<i>P06</i>	Offset	-2,0 ÷ +2,0	0	2
<i>P07</i>	Unit of measurement	0 (<i>bAr</i>) ÷ 1 (<i>PSI</i>)	0	0

NOTE: in case you set *P00* = 1, parameters *P01* ÷ *P06* are not visualized and during the operation the display visualizes the working temperature and compressor status only.

P05 is visualized only if the parameter *con* (Master/Slave - Multiunit operation) = **1** or **2** into menu 6 *CnF* (Compressor setting).

MENU 3 – *PH* = TEMPERATURES

Below all the parameters related to the temperature.

Parameter	Description	Setting range	Default	Password
<i>H00</i>	Enable temperature probe	0 (disabled) - 1 (KTY) 2 (NTC)	1	1
<i>H01</i>	High temperature	(<i>H02</i> +2) ÷ 125°C	110°C	1
<i>H02</i>	Warning high temperature	(<i>H03</i> +2°) ÷ (<i>H01</i> -2)°C	105°C	1
<i>H03</i>	Fan ON (RL5)	30 ÷ (<i>H02</i> -2)°C	70°C	1
<i>H04</i>	ΔT Fan OFF (RL5)	2 ÷ 20°C	10°C	1
<i>H05</i>	Low temperature	-10 ÷ +15	0 °C	1
<i>H06</i>	Offset	-10 ÷ +10 °C	0 °C	2
<i>H07</i>	Unit of measurement	0 (°C) ÷ 1(°F)	0	0

NOTE: the parameters *H03* and *H04* are visualized only if the parameter *rL5* = **1** into menu 6 *CnF*.

MENU 4 – P_t = WORKING TIMER

Parameter	Description	Setting range	Default	Password
t01	Star delta	2 ÷ 20 sec	5 sec	2
t02	Star/Delta timer	10 ÷ 50 ms	20 ms	2
t03	Delta timer	1 ÷ 900 sec	2 sec	2
t04	Unload timer	0 ÷ 10 min	4 min	1
t05	Safety timer	10 ÷ 240 sec	60 sec	2
t06	Master/Slave rotation	0 ÷ 200h	100 h	1
t07	Slave timer	1 ÷ 99min	5 min	1
t08	t04 fixed or variable	0 (fixed) ÷ 1 (variable)	0	1

NOTE

t06: set 0 disables Master/Slave switch.

t08: it is possible to set a fixed or variable unload timer.

Fixed: when the pressure reaches set P03 (stop) timer t04 starts counting; when the timer is over if the pressure is still over set P04 (start) the compressor stops; on the other hand if during the counting the pressure goes down set P04, the compressors shift to loading again and timer t04 reset.

Variable: the starting the compressor runs the unload fixed cycle above; on the next unload cycle the controller keeps the time that the pressure takes going down from set P03 to set P04: if this time (called tx), is lower than t04, on the next unload cycle t04 will be shorter (1 minute less) and so on up to a minimum time of 2 minutes.

As soon as tx is shorter than t04 modified, the setting value t04 is uploaded again as stop timer.

t05: this is the minimum time has to pass between stop and next start of the compressor.

The parameters t06 and t07 are visualized only if the parameter con = 102 (Master/Slave – Multiunit operation) into the menu 6 CnF (Compressor setting).

MENU 5 – P-F = MAINTENANCE TIMER

Into this menu you can set the maintenance timer.

Parameter	Description	Setting range	Password	Default
CAF	Change air filter	100 ÷ 3000	1	2.000 h
COF	Change oil filter	100 ÷ 10000	1	2.000 h
CSF	Change separator filter	100 ÷ 10000	1	4.000 h
C--	Change oil	100 ÷ 10000	1	8.000 h
C-h	Check compressor	100 ÷ 10000	1	500 h
bL	Lubricate motor bearings	100 ÷ 29999	1	29999

NOTE

The timer counting is related to ON time of RL1 and it comes backwards; when the timer reaches 0, it goes on as negative counting.

The hours storage comes every 15 minutes: if during the counting the power goes off, the part of 15 minutes is lost.

If you set C-h = 10000 the related maintenance message is not detected.

By changing the set value the residual time is recalculated.

Example: CAF, set 2000h, the counter is 1600, it means 400h has passed from reset. If you change the set, for example 3000, the counter will change into 2600.

MENU 6 – [nF = COMPRESSOR CONFIGURATION

Parameter	Description	Setting values	Password	Password
r--	Restart Low voltage	0 (manual) ÷ 1 (automatic)	1	1
S-h	Starts/hour	0 ÷ 60	2	2
FAd	Air flow	1000 ÷ 10000 l/min.	0	0
S--	Security	0 (no) ÷ 1 (yes)	2	2
In2	Input IN2	0 ÷ 5	2	2
In3	Input IN3	0 ÷ 5	2	2
In4	Input IN4	0 ÷ 5	2	2
rL5	Output RL5	0 ÷ 1	2	2
con	Connection	0 (single) – 1 (Master/Slave) – 2 (Multiunit Slave)	1	1
nc	Compressor no.	0 ÷ 32	1	1
OFL	Working mode	0 ÷ 1	1	1
dry	Dryer delay	0 ÷ 999	0	2

MEANING OF THE PARAMETERS SETTING
r--:

0: when the power supply to the controller goes down 9.0Vac, the compressor switches off; when the power comes back over 10.5Vac the display visualizes the alarm code **A07** keeping OFF status; the compressor must be manually restarted by the start button.

1: when the power supply to the controller goes down 9.0Vac, the compressor switches off; when the power comes back over 10.5Vac, the compressor starts automatically once the time **tOS** without visualizing any alarm.

S-h: this parameter set the max. starts the compressor (electric motor) can run in one hour.

In case the compressor reaches the set before one hour, it keeps on unload working till the hour time is over.

NOTE: if you set 0, the counting related to the starts/hours is cancelled.

FAd: here you can set the nominal air flow of the compressor.

This parameter is used on Multiunit operation by Logik33S / Logik200 to select the more efficient compressor according the pressure drop in the net.

S--: this parameter is related to the air filter change **CAF**.

0 = disabled

1 = enabled.

If you set 1 (enabled) when the timer **CAF** is over, the compressor shut off and the display visualizes the alarm code **A18**; you can reset the alarm only after you have reset the timer **CAF** into the related menu Reset.

In2 ÷ In4: you can set the 4 digital inputs according the followings:

In2: default 0 = OR alarms

0 = OR alarms

1 = thermal motor

2 = thermal fan

3 = phases sequence relay

4 = remote start/stop

5 = remote load/unload

In3: default 3 = phases sequence relay

0 = OR alarms

1 = thermal motor

2 = thermal fan

3 = phases sequence relay

4 = remote start/stop

5 = remote load/unload

ln4: default 4 = remote start/stop

- 0 = OR alarms
- 1 = thermal motor
- 2 = thermal fan
- 3 = phases sequence relay
- 4 = remote start/stop
- 5 = remote load/unload

rL5:

- 0:** RLS is set as alarm relay and the parameters **HO3** and **HO4** in menu **PH** are not visualized.
- 1:** RLS is set as fan contactor and the parameters **HO3** and **HO4** are visualized in menu **PH**.

con:

this parameter allows to set the compressor operation according the followings:

- 0** (single) = compressor works standing alone.
- 1** (Multiunit Slave) = the compressor works as Slave unit (serial communication) into a compressors system all having Logik controllers on board.
- 2** (Master/Slave) = the compressor works according Master/Slave operation (serial communication) together with another compressor with Logik controller on board.

nc:

in case of serial communication with other compressors (compressors net), here you must combine the number of the unit to detect the controller into the net.

OFL:

this parameter is visualized only if Multiunit operation has been enabled.

It allows to take the compressor out of the compressors management without stopping the entire system: i.e. in case of serve maintenance on the compressor.

- 0** (Multiunit operation available) = the compressor is managed into Multiunit operation.
- 1** (Multiunit operation not available) = the compressor is not managed into Multiunit operation; it works standing alone by its own internal pressure sensor.

dry:

this parameter allows to manage a dryer easily by delaying the start of the compressor for the time dryer needs to start.

The dryer is powered by the line contactor.

This parameter manages the delay after line contactor switches on and before the start/delta sequence.

In case the parameter setting is 0 the starting procedure is the one described in the chapter "Operating principle".

MENU 7 – Hr5 = WORKING HOURS

Here you can check out: total working hours, load working hours, starts/hour of the compressor, nominal air consumption and software release of the controller further to the maintenance timer in progress.

The display visualizes the name of the data (**tH**, **LH**, **S-h**, **FRd** **rEL**) and related value.

tH = total working hours

LH = load working hours

CAF = time to change air filter

COF = time to change oil filter

CSF = time to change separator filter

C-- = time to change oil

C-h = time to check compressor

bL = time to lubricate bearings

S-h = starts/hour

FRd = nominal air consumption

rEL = software release

By the buttons e/o ou can flow the timer.

IMPORTANT NOTE


It is possible to modify both "Working hours" and "Load working hours" only if you enable the password level 2.

By pushing  the first digit starts blinking to edit; select the new one by /or  confirm it by  to shift to the next one and set it according the same procedure.

Once you confirm the last digit, the new value is loaded into the controller.

MENU 8 – AL = ALARMS

Here it is the visualization of the last 20 alarms detected; the 21st erase the first one and so on.



In the picture above: **13** is the alarm code detected (make reference to the alarms list in this manual) and **02** is the number of times the alarm has been detected.

8 is the number of the menu you are in, represented by the code **AL**.

By the buttons  and/or  you can flow the alarms list up and down.

On case there is not any alarm stored, the display visualizes the message "--".

MENU 09 – rES = RESET

This menu is dedicated to the reset of the following menu:

P-F = Maintenance timer (password level = 1)

R-L = Alarms list (password level = 1)

HrS = Working hours (password level = 2)

G-G = General reset and upload of default values (password level = 2)

When you enter this menu by the button  the display is the following:



By the buttons  and/or  select the menu you need to reset and execute it by pushing  for about 3 seconds: the display visualizes the blinking message **rES** for a while to confirm reset in progress.

NOTE TO MAINTENANCE TIMER RESET: in case you confirm **P-F** (maintenance timer) the display visualizes the following:



By pushing  and/or  you can flow the maintenance timers to allow reset one by one: to understand the meaning of the nomenclature make reference menu "5 – **P-F** Maintenance timer" page 14.

Execute the reset as above, by pushing  for about 3 seconds.

IMPORTANT NOTE: General Reset is allowed when the compressor is OFF only.

ALARM CODES

SHUT OFF ALARMS

Reset to shut off alarms is allowed by pushing  when compressor is absolutely OFF.

CODE	DESCRIPTION	CAUSE
AD1	REVERSED PHASE	Input used to sequence phase relay open (IN3)
AD2	HIGH TEMPERATURE	Temperature detected by the probe is over set HD1
AD4	LOW TEMPERATURE	Temperature detected by the probe is below set HD5
AD5	TEMPERATURE PROBE FAILURE	Temperature probe is faulty
AD7	LOW VOLTAGE	Power supply to the controller lower than 9Vac
AD9	SECURITY PRESSURE SWITCH	All inputs IN1 ÷ IN4 open
AL10	HIGH PRESSURE	Pressure detected by the transducer is over set PD2
AL11	PRESSURE TRANSDUCER FAILURE	Pressure transducer is faulty
AL12	EMERGENCY STOP BUTTON	Input to emergency stop button open (IN1)
AL13	THERMAL MOTOR	Input used to thermal motor open (IN2, IN3 or IN4)
AL14	THERMAL FAN	Input used to thermal fan open (IN2, IN3 or IN4)
AL15	OR ALARMS	Input used to OR alarms open (IN2)
A18	SECURITY	Parameter S-- set = 1: reset timer CAF to be able to reset this alarm
A19	FIELD BUS ERROR	Watchdog via MODBUS is activated: 5 seconds timeout is over without any reply from the Master (see MODBUS document)
PDF	POWER FAULT	Compressor set as per manual restart; in case of power off while the power comes back the compressor keeps off and visualizes this alarm code

NOTE: when the compressor shut off all the relays are switched off while RL5 switches on (in case into menu 6 - **CAF** parameter **rLS = 0**).

WARNINGS (VISUAL ALARMS)

Reset to warning is possible by pushing  while compressor is working.

CODE	DESCRIPTION	CAUSE
AD0	SET DATA LOST	EEPROM failure or firmware upgraded
AD3	FOREWARNING HIGH TEMPERATURE	Temperature detected by the probe over set HD2 (automatic reset)
AD6	WITHOUT TEMPERATURE PROBE	Parameter HD0 set 0 and display visualizes "---"
AD8	MAX. STARTS/HOUR	Compressor starts as many times as value set on S-h . You can reset by increasing parameter starts/hour or waiting for expiring hour
A16	MULTIUNIT FAILURE	Master unit failure or no communication to Master unit
A17	MASTER/SLAVE FAILURE	NO serial communication between the compressors
A18	WITHOUT TEMPERATURE PROBE	Parameter HD0 set 0

NOTE: when warning is detected, RL5 switches on intermittently (in case into menu 6 - **CAF** parameter **rLS = 0**).

MAINTENANCE CODES

Reset to maintenance codes is possible by pushing  while compressor is working.

CODE	DESCRIPTION	CAUSE
F-A	CHANGE AIR FILTER	Timer CAF over
F-O	CHANGE OIL FILTER	Timer COF over
F-S	CHANGE SEPARATOR FILTER	Timer CSF over
O-L	CHANGE OIL	Timer L-- over
L-h	CHECK COMPRESSOR	Timer L-h over
bL	LUBRICATION BEARINGS	Timer bL over

NOTE

- 1) Shut off alarm codes have priority to warnings while warnings have priority to maintenance codes.
- 2) When you reset a maintenance code visualized on the display while related timer has not been reset yet into appropriate menu **rES**, every power on the display keep on visualizing the same maintenance code.
- 3) Both alarm and maintenance code are visualized during all compressor status.
- 4) In case of maintenance messages, after carried out maintenance on the compressor you have to reset the counter in the menu **P-F**; if you don't do that, every 50 working hours or every time you switch on the compressor the message is visualized again.

OPERATING PRINCIPLE

1) Power on:

- a) the display visualizes message **OFF**;
- b) all relays are OFF.

2) Compressor ON by pushing start button and the display visualizes the pressure detected (according setting on parameter **P00**), working temperature and compressor status: the display visualizes  to indicate RL4 status (load solenoid valve).

Safety timer **t05**

By pushing the stop button the compressor stops according the following procedures:

- a) If the compressor is running load shift to unload for the time set on **t04**; during this counting restart by start button is allowed.
When time **t05** is over the compressor stops and the display visualizes the message **OFF**;
- b) if the compressor is running unload and **t04** counting is higher than **t05**, once **t04** is over the compressor stops and the display visualizes the message **OFF**;
- c) if the compressor is running unload and **t04** counting is lower than **t05**, the compressor stops and the display visualizes the message **OFF** while **t05** is over only;
- d) if the compressor is OFF while it has reached the pressure set, it stops and the display visualizes the message **OFF**;

When the compressor stops and the display visualizes the message **OFF**, timer **t05** starts; during this counting in progress if you push the start button the message **On** starts blinking alternating the pressure (according the set on parameter **P00**) and the compressor will start when timer **t05** is over only.

In case the compressor stops due to shut off alarm, timer **t05** starts; during timer in progress if you reset the alarm and push the start button, the message **On** starts blinking alternating the pressure (according the set on parameter **P00**) and temperature detected and the compressor will start when timer **t05** is over only.

Remote start/stop

If you set one of the input (IN2 – IN3 – IN4) as remote start/stop when the compressor is ON by start button  if the input related to remote start/stop opens the display visualizes the message **OFF** with related icon  and the compressor switch to unload working according the same principle and time related to the pushing of the stop button above.

When the compressor switch from load to unload working through remote start/stop the display visualizes the message **OFF** alternating the pressure (according the set on parameter **P00**) and the temperature detected.

Load solenoid valve operation (RL4)

1) t_{08} set as fixed time = 0

When the pressure reaches stop set, RL4 switches **OFF** and the display visualizes the pressure (according the set on parameter $P00$) and the temperature and t_{04} starts; once the timer is over, if the pressure is not lower than the start set, the compressor stops; during timer in progress if the pressure goes down start set, the load solenoid valve RL4 switches **ON** and the display visualizes the pressure (according the set on parameter $P00$) and the temperature while timer t_{04} erases.

2) t_{08} set as variable time = 1

The starting the compressor runs the unload fixed cycle above; on the next unload cycle the controller keeps the time that the pressure takes going down from set $P03$ to set $P04$: if this time (called tx), is lower than t_{04} , on the next unload cycle t_{04} will be shorter (1 minute less) and so on up to a minimum time of 2 minutes.

As soon as tx is shorter than t_{04} modified, the setting value t_{04} is uploaded again as stop timer

Fan operation ($rL5 = 1$)

When delta contactor is ON (RL3), the fan contactor (RL5) is operated according the following principle:

- a) if the air end temperature is equal or higher than the set value on the parameter $H03 = RL5$ ON;
- b) if the air end temperature is lower than the value ($H03 - H04$) = RL5 OFF.

Restart after black out

Menu **[nF]** - parameter $r---$

Manual:

in case of black out when the power is restored, the compressor does not restart automatically and the display visualizes the message **POF**; after you reset the alarm message by the button  the compressor shift to RUN position. The alarm code is stored into the alarm list.

Automatic:

in case of black out when the power is restored the compressor restart from the status previous to black out: if the compressor was ON it restart according the principle above, after the timer t_{05} is over; during t_{05} in progress the display visualizes the blinking message **On**. Anyway the alarm code **POF** is stored into the alarm list.

MASTER SLAVE OPERATION

Master/Slave operation allows to put two compressors in communication via serial line for the optimal management on air consumption.

NOTE: Master/Slave operation is allowed only between two compressors equipped with Logik controller.

Above all check out the compressors are in communication through the proper serial port terminal at disposal.

Check into menu **Pt** the parameters **t06** (timer to shift Master into Slave and Slave into Master) and **t07** (timer to start Slave compressor in case Master does not reaches the stop set after first start up) are set according your need.

If the working hours difference between the two compressors is higher than set **t06**, the machine having less working hours keeps on working till it reaches the same hours of the other + the working hours set on **t06**; after this time only the Master Slave shift is activated.

During Master/Slave operation the following parameters are common to both compressors:

P02-P03-P04-P05, Manual / Automatic restart (**r--**), timers **t06** and **t07**.

Changing one of the above parameters on one compressor, modification is transferred automatically to the other.

Pushing the Start button of one of the two compressors both are activated

Pushing the stop button of one of the two compressors both are put in OFF

Slave compressor operates only if:

- 1) First start up Master does not reach the stop pressure until time set on **t07**.
- 2) Pressure goes down set on **P05**.

NOTE: the compressor stops when it reaches the pressure set **P03**.

Master Slave shift when:

- 1) timer set on **t06** is over.
- 2) In case of shut off alarm on Master unit.

NOTE

- In case you have to serve one of the two compressors before to stop it you have to set both units for standing alone operation (menu **LnF** - parameter **con** = 0) and then set again Master/Slave operation after maintenance (menu **LnF** - parameter **con** = 1).
- In case of serial line failure both compressors are Master to work standing alone.

MULTIUNIT OPERATION

Multiunit function (configured on a net of Logik controllers up to 5 units max.), allows the cooperative operation of the compressors managed.

All the controllers must be connected on bus RS485 and you have to set a MODBUS address to each one: pay attention addresses must be different one to one. You can choose the addresses into a range from **1** to "**n**", where "**n**" is the number of controllers into the net.

It is strictly necessary one of the compressors is configured as "Master Multiunit" and this unit must have MODBUS address = 1.

Till on Master unit you set the number of "Slaves": in other words the other compressors into the Multiunit net.

NOTE: Master unit CAN BE Logik31-S or Logik33-S ONLY.

Till on Master unit you set the operating principle amongst: Smart, Balance Hours or Priority (for further details make reference to the manual of the Master controller).

The parameters of Logik9 interested to the Multiunit operation are the followings (menu 6 **CONF**):

- **con**: set 2 to operate Logik9 as Multiunit Slave.

- **nc**: set a value between 2 and **n**, where **n** is the number of compressors into the Multiunit net.

Pay attention to set different addresses into the different controllers.

- **FAd**: it is the air flow (Liters/minutes) of the compressor; Master unit needs this data to match the best compressor to operate in relation to the air consumption of the plant, in case of Smart operating principle.

- **DFL**: in case you need to carry out maintenance, if you set this parameter = 1, you can exclude the compressor from the Multiunit operation and stop it to serve.

During Multiunit operation the display shows the icon  the main visualization.

The pressure detected is the one Master detects and this detection is used to operate/manage the compressors according the air demand from the plant.

Icon  blinks in case of communication error to the Master or pressure transducer failure till on the Master unit.

If the remote start/stop inputs on Master opens, all Multiunit net switch to stand-by status and the display shows  on the main visualization.

In case the compressor is not under maintenance (**DFL** \neq 1), if you push ON/OFF button on Logik9, all the compressors into Multiunit net start/stop through a command sent to Master.

Further information on the management and operation of the compressors, make reference to the instruction manual of the Master unit.

WARRANTY TERMS

24 (twenty-four) months from the production date printed on the label of the serial number.

Temperature probe is not included in the warranty terms.

Both working and technical features of the controller must be fully respected: the warranty declines if the controller has been opened or repaired by unauthorized personnel.

Operation or modification different from the original, wrong electrical wiring or bad assembling can be cause of failures or malfunctioning of the controller; in these cases both warranty and own technical features of the controller declines.

Technical features, drawings, and any other document in this manual are property of Logika Control that forbid any reproduction, even partial, of text and illustrations.

On its unquestionable judgement, Logika Control reserves the authority to modify the product to improve operation and performance, besides to the right to withdraw the product from the production, in any time and without notice.

REVISION INDEX

Revision 0 = Issue

Revision 1 = upgrade to parameter dry function



Dichiarazione di Conformità 
EC Declaration of Conformity 

Noi sottoscritti,
We the undersigned,

Logika Control s.r.l
Via Garibaldi, 83/A - 20834 Nova Milanese (MB) Italia

Certifichiamo e dichiariamo sotto la nostra responsabilità che i seguenti prodotti:
certify and declare under our sole responsibility that the following apparatus:

Descrizione <i>Description</i>	Controllo elettronico per compressori <i>Electronic controllers for compressors</i>
Marca <i>Brand name</i>	Logika Control
Modello <i>Type model</i>	LOGIK 9 (0KLC5L4A)

è conforme ai requisiti essenziali delle seguenti direttive:
conforms with the essential requirements of the following directives:

Compatibilità Elettromagnetica 2004/108/CE
EMC 2004/108/EC,

Bassa Tensione 2006/95/CE
LVD 2006/95/EC

ROHS 2011/65/EU
ROHS 2011/65/EU

e sono state applicate le seguenti norme armonizzate:
based on the following harmonized standards applied:

EN 60730-1
EN 50581

Data / Date
2015/03/01



Dott. Fabio Udine
Amministratore Delegato

