



Micro Compressor Controller (MCC)

Operation Manual

SHENZHEN SULLAIR ASIA INDUSTRIAL CO., LTD.

Part No.: 88290016-026
Rev. 06– Feb 2009



SULLAIR®

Preface

This manual describes the system structure, function, usage and maintenance method for Micro Compressor Controllers.

Before installing and operating this machine, customer shall carefully read this manual. After fully understanding the structure and function of each part of the machine set can they operate and maintain the machine set.

From time to time, the product is being redesigned to seek improvement. After certain period, there will be discrepancies between this manual and the product itself. The user should be aware of it.

If there is any point that is not described in this manual but is unclear during the operation and use by the user, you can contact your local distributor of Sullair co., or Customer Care by Sullair of Sullair Co.

——Editor
January, 2008



SULLAIR®

TABLE OF CONTENTS

| | | |
|-----|---|----|
| 1. | GENERAL INFORMATION | 1 |
| 2. | SAFETY INSTRUCTION | 1 |
| 3. | INTRODUCTION..... | 2 |
| 4. | SPECIFICATION..... | 2 |
| 5. | OPERATORS' INTERFACE | 3 |
| 6. | DISPLAYS, CONFIGURATION & SETPOINTS..... | 4 |
| 6.1 | STARTUP | 4 |
| 6.2 | STATUS DISPLAY | 4 |
| 6.3 | SETUP GUIDE | 4 |
| 6.4 | CUSTOMER SETTING | 5 |
| 7. | INSTALLATION | 6 |
| 7.1 | MECHANICAL INSTALLATION | 6 |
| 7.2 | ELECTRICAL WIRING DIAGRAM..... | 7 |
| 7.3 | CONTROLLER CONNECT TERMINALS | 7 |
| 8. | CONTROL FUNCTIONS..... | 8 |
| 8.1 | AUTOMATIC CONTROL – LOCAL MODE..... | 8 |
| 8.2 | AUTOMATIC CONTROL – REMOTE MODE..... | 8 |
| 9. | ALARM AND FAILURE PROTECTION..... | 9 |
| 9.1 | FAILURE STOP AND EMERGENCY STOP | 9 |
| 9.2 | AIR FILTER ALARM | 9 |
| 9.3 | OIL FILTER ALARM..... | 9 |
| 9.4 | OIL SEPARATOR ALARM..... | 9 |
| 9.5 | FLUID ALARM..... | 9 |
| 9.6 | GREASE ALARM..... | 9 |
| 9.7 | HIGH DISCHARGE PROTECTION | 9 |
| 9.8 | COMPRESSOR ANTI-REVERSION PROTECTION..... | 9 |
| 9.9 | SENSOR FAILURE PROTECTION | 9 |
| 10. | TROUBLESHOOTING GUIDE..... | 10 |
| 11. | MCC CONTROLLER REPLACEMENT AND SET-UP INSTRUCTIONS..... | 11 |



SULLAIR®

1. GENERAL INFORMATION

Warning:

DO NOT install, operate, maintain, adjust or service Micro Compressor Controllers without thoroughly reading this manual.

Disclaimer:

The information in this document is subject to change without notice. While Sullair assumes and believes the information contained herein to be accurate, the company assumes no responsibility for any errors or omissions.

Copyright notice:

No part of this document may be reproduced in any form without prior written consent of Sullair. The software described in this document is furnished under a license and may only be used or copied in accordance with the terms of the license.

2. SAFETY INSTRUCTION

When using air compressors and compressed air accessories, basic safety rules and precautions must always be followed including the following:

- I) Read all instructions fully.
- II) Electrical Safety Precautions.



WARNING : **Risk of Danger**



WARNING : **Risk of Electric Shock**



WARNING : **Risk of High Pressure**



WARNING : **Consult Manual**

When installing, commissioning, operating or carrying out maintenance on the MCC unit, the respective persons must use safe working practices and observe all relevant local health and safety requirements and regulations.

Use extreme cautions when carrying out electrical checks. Isolate the power supply before starting any maintenance work.

Do not operate the MCC unit with damaged wiring/ parts after the controller unit have been dropped or damaged in any manner. Notify authorized service facility for examination, repair or other adjustments.

It is not possible to anticipate every circumstance, which might represent a potential hazard. If the user employs an operating procedure, an item of equipment or a method of working which is not specifically recommended, the user must ensure that unit will not be damaged or made unsafe and that there is no risk to persons or property. Failure to observe safety precautions or implement safe working practices may be considered dangerous practice or misuse of the product.

3. INTRODUCTION

Micro Compressor Controller (Abbr. MCC) displays temperature, pressure, operation time and working status of the compressor through 2×8 liquid crystal display (LCD).

The information can be displayed in Chinese or English or other languages (The language requirement should be stated in sales order). Compressor information can be uploaded via RS485 Modbus protocol.

Operator can control the compressor, set parameters and display needed parameters through the keypad on the control panel. Indicator lights on the panel reflect the basic status of the device (refer to Fig.1).

4. SPECIFICATION

1. Digital Inputs: Digital input 4-channel
2. Digital Output: Digital switching output 5-channel.
3. Analog Inputs: Pt1000 temperature input 1-channel; 4~20mA transferred input 1-channel;
4. USB port for program downloads in different languages.
5. Power supply: 90-130VAC, 50/60HZ, 40mA .
6. Display ranges
 - a) Temperature: -20~150℃; Accuracy: $\pm 1^{\circ}\text{C}$
 - b) Run time: 0~999999H
7. Temperature Protection: When the actual temperature is higher than the rated allowed temperature, the function will be activated in less than 2s.
8. Output relay contactor capacity: 250VAC/5A; 500000 switching times;
9. Ambient temperature: -20℃ – 65℃

5. OPERATORS' INTERFACE





Fig. 1



Start Key: Press this key to start the compressor.



Stop Key: Press this key to stop the compressor (when pressing this key, the compressor immediately turns to unload mode and stops after ** seconds (which can be set in CUSTOMER SET). If the compressor has been unloaded for ** seconds (saved number) before pressing the key, the unit will stop immediately.)

S Set key / Load / Unload: Press this key to save modified data. When compressor is running, press this key to send load or unload command to the compressor.



Up key: Press this key to move upward (add) in data modification or move upward scroll in menu operation.



Down key: Press this key to move downward (reduce) during data modification or downward scroll in menu operation.



Cursor/Confirm Key: This key is treated as cursor during data modification and as confirm key during menu selection




Return / Reset Key: Press this key to return to upper menu during the menu operation / long held to reset the unit current state when the compressor is stopped due to a failure. Press this key to stop buzzing.

6. DISPLAYS, CONFIGURATION & SETPOINTS

6.1 STARTUP

After power on, the MCC will display the following two interfaces. Each menu lasts up to 3 seconds before turn to main interface, e.g.:

| | |
|---|-------------------------------------|
|  SULLAIR CO3-CXXXXXX | RUN: xxxxxx H REV:03 2007/01 |
|---|-------------------------------------|

SULLAIR is the logo of SULLAIR Corporation.

CO3-CXXXXXX is the serial number of the compressor unit.

RUN: XXXXXX H is overall operation time of the device.

REV: 03 is the software version.

2007/01 is shipping date of MCC.

The main interface:

| |
|-------------------------|
| STOP 180°F 75PSI |
|-------------------------|

6.2 STATUS DISPLAY

Press “▼” key to read the running parameters directly. For example, if pressing “▼” key for the first time, the overall operation time displayed as bellow.

| |
|--------------------------------|
| TOTAL RUN TIME: ***** H **M |
|--------------------------------|

Press “▼” key to read the following status:

| | | |
|----------------------|---------------|------------------------|
| LOADED TIME | FLUID | PRODUCTION DATE |
| | GREASE | SERIAL NO. |
| THIS RUN TIME | ALARM1 | CUSTOMER SET |
| THIS LOADING | ALARM2 | FACTORY SET |
| OIL FILTER | ALARM3 | |
| A-O SEPARATOR | ALARM4 | |
| AIR FILTER | ALARM5 | |

6.3 SETUP GUIDE

Note: The customer and factory parameters are prevented from being modified while the unit is running or in the stop delaying period.

Navigate to the last two menus: ‘CUSTOMER SET’ and ‘FACTORY SET’ by pressing ‘▼’, or by pressing ‘▲’ on the main interface to the ‘CUSTOMER SET’ and ‘FACTORY SET’ immediately.

| |
|------------------------------------|
| CUSTOMER SET FACTORY SET |
|------------------------------------|

⇒ From a menu, the various items within it can be viewed by scrolling with the “▼” or

“▲” key.

- ⇒ Menus are accessed with the “▶” key, pressing this key will a sub-menu is displayed will activated that particular sub-menu:

LOAD PRESS:
006.5BAR

- ⇒ To scroll to another sub-menu press “▼”.
⇒ To modify parameter within the same menu, press “▶” on the parameter, the password input screen will be displayed.

PASSWORD ****



Note: Customer password can be modified in customer parameter.

If the entered password is correct the parameter to be modified will return to the display and flash.

- ⇒ The parameter now can be modified by pressing “▼” or “▲” key.
⇒ To modify another parameter within the same menu,”▶” is used to move the cursor to the next number. Press “S” key as confirmation.
⇒ To modify other parameters within the same menu, scroll to the new parameter and depress “▶” key.
⇒ To end the parameters modification, press “◀” key to return to the main interface.

6.4 CUSTOMER SETTING

All the customer parameters have been preset by SULLAIR according to SULLAIR product requirements.

| Parameter | Preset Value | Description |
|-----------------|--------------|---|
| LOAD PRESS | ***.* BAR | Load pressure value |
| UNLOAD PRESS | ***.* BAR | Unload pressure value |
| MTR START TIME | 0008 S | To protect motor, MTR START TIME must be longer than the STAR DELTA TIME plus LOAD DELAY TIME |
| DRAIN/REMOTE | Remote | When set as DRAIN, the No. 18 terminal is the connector for drain control, draining periodically. When ON/OFF MODE is set as REMOTE and here set as REMOTE, the No. 18 terminal is the connector for remote control indication. |
| STAR-DELTA TIME | 0006S | Y-△ starting transition time. For full voltage starting, set the value as “0” |
| LOAD DELAY TIME | 0002S | The delayed time from star-delta transition or full-voltage starting completion to be on loading. |
| UNLOAD RUN TIME | 1200S | Maximum time from unloading to standby mode. |
| STOP DELAY TIME | 0010S | The delayed time from pressing the stop key to be shutdown. |
| RESTART TIME | 0060S | Delay time before restart. |
| ON/OFF MODE | LOCAL | Press  key to enable remote control mode. If compressor is shutdown by pressing  , remote control will be disabled. |
| LOAD MODE | AUTO | The Load / Unload function can be modified by pressing “S” key in manual mode. |

| | | |
|-----------------|----------|--|
| CLEAR OIL FILT | 0000H | Reset time after oil filter changed |
| CLEAR A-O SEP | 0000H | Reset time after oil separator changed |
| CLEAR AIR FILT | 0000H | Reset time after air filter changed |
| CLEAR FLUID ALM | 0000H | Reset time after fluid changed |
| CLEAR GREASE AL | 0000H | Reset time after grease changed |
| OIL FILT CHANGE | 1000H | Set to '0000H' to disable the oil filter alarm function |
| A-O SEP CHANGE | 4000H | Set to '0000H' to disable the oil separator alarm function |
| AIR FILT CHANGE | 1000H | Set to '0000H' to disable the air filter alarm function |
| FLUID CHANGE | 8000H | Set to '0000H' to disable the fluid alarm function |
| GREASE REQ | 2000H | Set to '0000H' to disable the grease alarm function |
| USER PASSWORD | **** | To modify the customer password |
| COM MODE: | PC | If DISABLE, communication cannot work. If SEQ, multiple machines can work in sequence mode. If PC, communicate as slave with external equipment according to MODBUS protocol |
| COM ADDRESS | 0001 | Communication address |
| SEQUENCE STATE | MASTER | Master or Slave mode when there are more than one compressors running in SEQUENCE mode |
| SEQUENCE NO. | 0004 | Total number of compressors in sequence network. |
| SEQ LOAD PRESS | ***.*BAR | During sequence control, when master pressure is lower than SEQ LOAD PRESS, and SEQ DELAY is up, the master will find a compressor in the net to load or start. |
| SEQ UNLOAD PR | ***.*BAR | During sequence control, when master pressure is higher than SEQ UNLOAD PR, and SEQ DELAY is up, the master will find a loading compressor in the net to unload or stop. |
| SEQ DELAY | 0015S | During sequence control, continuously send control interval time. |
| LANGUAGE SEL | CHINESE | Select display languages |
| | | |
| | | |
| DRAIN OPEN | 0010S | Draining time in auto drain control (only effective in on load mode) |
| DRAIN CLOSE | 0003M | Interval time in draining (only effective in on load mode) |
| TEMP UNITS | ℃ | Temperature unit can be set as ℃ or °F. |
| PRESSURE UNITS | BAR | Pressure unit can be set as BAR or PSI |
| ROTATE HOURS | 0001H | Rotate hours between slaves in sequencing network |

7. INSTALLATION

7.1 CONTROLLER INSTALLATION

The controller is installed with bolts' size 72 x 122. Certain space should be left around controller for wiring. The specific dimensions are as follows:




Fig.2 Controller outline dimensions

7.2 ELECTRICAL WIRING DIAGRAM




Figure 3. Electrical wiring diagram

7.3 CONTROLLER CONNECT TERMINALS

Controller terminals:

4 and 5 are RTD signal input; 6 is remote controlled on/off signal input terminal; 7 is PR XDRC signal input terminal; 8 is input terminal for overheat signal of fan motor; 9 is input terminal for emergent stop signal; 10 is common terminal for input signals; 11 is RS485 A; 12 is RS485 B; 18 is electronic drain valve/remote control (optional) output; 19 loading valve; 20 controls main contact switch; 21 star contactor; 22 delta contactor; 23 is common terminal COM1 of output relay; 24 is the analog grounding; 25 and 26 are the AC 110V power source input.


NOTE! The magnetic coils of valves and contactor must be connected to a surge absorber.

8. CONTROL FUNCTIONS

8.1 AUTOMATIC CONTROL – LOCAL MODE

(Load mode: Automatic On/off, local start control mode)

① MOTOR STARTING:

The controllers perform a 6 seconds self-checking after power on during which the  key can not start the machine. Starting procedure of compressor is: KM1 (Main/Line contactor) power on →, Motor in Y starting → Transition time over (Y—△ transition time), KM2 power off (KM2 and KM3 interlocked) → Motor running in △ mode, motor starting over.

Note: All the solenoid valves are power off during the motor starting to ensure the no-load starting. If compressor is full voltage (not Y—△) starting, power on KM1.

② AUTOMATIC RUNNING CONTROL:

The load solenoid valve power on after the motor is running in △ mode for certain time (LOAD DELAY TIME), the inlet valve opens and pressure rises.


The load solenoid valve will power off when the air pressure reaches the rated unload pressure (UNLOAD PRESS), the compressor will change into unload process.

If in the specified time (UNLOAD RUN TIME) the air pressure turns to be lower than the set load pressure (LOAD PRESS), the load solenoid valve will restart and the compressor will changes into on-load process.

If the unload run time exceeds the “UNLOAD RUN TIME” set in the customer parameters, the compressor will automatically stop.

Only if the pressure reaches lower than the load pressure limit (LOAD PRESS), the compressor will restart according to the normal starting process and so on.

③ NORMAL STOPPING:

By pressing the  key the load solenoids valve powers off, after certain time (STOP DELAY TIME), all controller relays will power off, main and fan motor stop running. The compressor can be restarted only after the restart delay time decrease to “0”.



④ ANTI-FREQUENTLY-STARTING CONTROL

The motor can not be started immediately after stopping unless after (RESTART TIME), or if the compressor stopped after (UNLOAD RUN TIME). Whatever the situation is, the controller will display remain time of delay (such as 90s). The motor can only be started when the delay time is 0.

8.2 AUTOMATIC CONTROL – REMOTE MODE

(Load mode: Automatic On/off, Remote start control mode)

① MOTOR STARTING:


The controller performs a 6 second self-check prior to press the  key to start the machine. If “DRAIN/REMOTE” is set as remote, the No.18 terminal serves as remote control enable signal input. After  key has been pressed, the compressor can be started or stopped by controller No.

6 terminal. Start signal is to be received via the No.6 terminal, the motor starts as in the local control mode.

② AUTOMATIC RUNNING CONTROL:

Refer to the local automatic running mode.

③ REMOTE STOPPING:

To signal a remote stop, terminals 6 and 10 must be open circuit and then the load solenoid valve will lose power, all controller relays will lose power after the stop delay time (STOP DELAY TIME), the main and fan motor will stop running thus remotely stopped the compressor. Only when the restart delay time counts to “0” can the compressor be restarted remotely by remote start signal from terminals 6 and 10. Only when user presses the local  key will the remote start/stop enable signal clear off, the compressor can not be started by remote control.

④ FREQUENT STARTING PREVENTION CONTROL

Refer to local starting procedure descript above.

9. ALARM AND FAILURE PROTECTION

9.1 FAILURE STOP AND EMERGENCY STOP

When there is any electronic sensor failure, overload failure or high discharge temperature failure, the controller will stop the motor running immediately. The motor can only be restarted after the failures are cleared.

The emergency stop key is to be pressed to cut off the power supply of the controller and contactors in any emergent errors situation, which will immediately stop the compressor motor.

9.2 AIR FILTER ALARM

When air filter reaches the set run time limit, the display will read “AIR FILTER ALM”.

9.3 OIL FILTER ALARM

When oil filter reaches the set run time limit, the display will read “OIL FILTER ALM”.

9.4 OIL SEPARATOR ALARM

When oil separator reaches the set run time limit, the display will read “A-O SEPARATOR”.

9.5 FLUID ALARM

When lube reaches the set run time limit, the display will read “FLUID CHANGE”.

9.6 GREASE ALARM

When grease reaches the set run time limit, the display will read “GREASE CHANGE”

9.7 HIGH DISCHARGE PROTECTION

When discharge temperature exceeds the set temperature limit, the controller will alarm or stop, the display will read “HIGH DISCH TEMP”

9.8 SENSOR FAILURE PROTECTION

When a pressure or temperature sensor fails, controller will alarm and stop. The failure displayed on the controller is “PR XDCR FAULT” or “RTD FAULT”.

10. TROUBLESHOOTING GUIDE

Example: The fault caused by exterior parts can be display on the control panel. e.g.

STOP:
RTD FAULT

In this condition check the temperature sensor to see whether wire is broken or damaged.

The relevant warning information shall popup on the screen in case of other faults.

The following table listed minor issues, causes and solutions.

| Alarm | Causes | Solutions |
|-----------------|--|--|
| OIL FILTER ALM | Improper parameter setting and consumable life expires | Parameter adjustment, maintenance |
| A-O SEPARATOR | Improper parameter setting and consumable life expires | Parameter adjustment, maintenance |
| AIR FILTER ALM | Improper parameter setting and consumable life expires | Parameter adjustment, maintenance |
| FLUID CHANGE | Improper parameter setting and consumable life expires | Parameter adjustment, maintenance |
| GREASE CHANGE | Improper parameter setting and consumable life expires | Parameter adjustment, maintenance |
| HIGH DISCH TEMP | Poor cooling, oil shortage, improper parameter setting | Parameter adjustment, vent enhancement, proper lubrication |

The following table lists big issues, causes and solutions.

| Faults | Causes | Solutions |
|------------------------|--|--|
| PR XDCR FAULT | Wire broken, transducer damaged, etc | Check wiring, replace damaged transducer |
| RTD FAULT | Cable off, PT1000 failure, etc | Check wiring, Replace PT1000 |
| HIGH DISCH TEMP | High temperature, inaccurate sensor and wrong parameter | Check machine temperature sensors, check parameter |
| HIGH PRESSURE | Over pressure, inaccurate sensor and wrong parameter | Check machine pressure, pressure sensor, check parameter |
| MOTOR OVERLOAD | Low voltage, high pressure, bearing failure, separator blocked or other mechanical damages or data distortion etc. | Check the set data, Voltage, bearings, separator tubes and other mechanical faults |
| | | |
| Main contactor failure | Emergency stop key wiring loose | Check wiring. Check Contactor |
| | | |

11. MCC CONTROLLER REPLACEMENT AND SET-UP INSTRUCTIONS

- 1 Read Section 1—Safety in MCC Controller User Interface Manual. Follow all safety guidelines.
- 2 Disconnect incoming power.
- 3 Open starter enclosure door and unplug connectors from existing controller.
- 4 Loosen screws on installation clips and remove controller.
- 5 Install new controller and gasket.
- 6 Plug connectors into controller, close enclosure door and turn on power to machine.
- 7 Modify setting accordingly
- 8 Confirm pressure setting as follows:
 - a. Slowly open the shut-off valve to the service line.
 - b. Press the START pad to start the compressor in default mode (AUTO).
 - c. Check for leaks in service air piping.
 - d. Slowly close the service line shut-off valves to verify nameplate pressure unload setting.The compressor should unload when nameplate pressure is achieved.
- 9 Adjust other customer settings (maintenance intervals, units, operating mode) as desired.
Refer to the Micro Compressor Controller Operation Manual
Section 6.4— Customer setting



SULLAIR®

Global Sales and Service



Headquarter USA: SULLAIR CORPORATION

Subsidiary of Hamilton-Sundstrand Corporation, a UTC company
3700 East Michigan Boulevard
Michigan City, Indiana 46360 U.S.A.
Telephone: 001-219-879-5451 or
1-800-Sullair (U.S.A. only)
Fax: 001-219-874-1273
Fax: 001-219-874-1835 (Parts)
Fax: 001-219-874-1805 (Service)

SULLAIR EUROPE

Zone Des Granges BP 82
42602 Montbrison Cedex, France
Telephone: 0033-4-77968470
Fax: 0033-4-77968499

SULLAIR ASIA

Zuo Paotai Road, Chiwan, Shekou, Shenzhen, P. R. China 518068
Tel: 0755-26851686
Fax: 0755-26853473, 26853475
Service hotline: 800-830-3977

SULLAIR AUSTRALIA

11-15 Marlo Place, Hallam, Victoria 3803, Australia
Tel: 61-3-9703-8000
Fax: 61-3-9703-8077