



Controller Manual

Neuron III

Version 3.6
July 2020

Contents	Page No.
Abbreviations used	7.4
7.1. Technical specification	7.5
7.2. Installation instruction	7.7
7.2.1 Equipment's safety	7.7
7.2.1.1 Static discharge warning	7.7
7.2.1.2 Assembly	7.7
7.2.1.3 Electrical connection	7.7
7.2.1.4 Power supply	7.7
7.2.2 General instruction	7.7
7.3. Display & terminal details	7.8
7.3.1 Terminal connection	7.8
7.4. Neuron-III salient features	7.9
7.4.1 Home screen display	7.9
7.4.2 Records (view-> day report and fault report)	7.9
7.4.3 Remote function (both MODBUS as well as digital input)	7.9
7.4.4 Lead and lag – pressure schedule (operator-> schedule)	7.9
7.4.5 Other interfaces and communication	7.9
7.4.6 Safeguard	7.9
7.4.7 Mimic LED for fault indicators	7.9
7.5. Input output description	7.10
7.5.1 X01: Power supply	7.10
7.5.2 X02: Digital inputs	7.10
7.5.3 X03: Analog input/output	7.10
7.5.4 X04: RS 485 communication	7.10
7.5.5 X05: Main motor relays	7.11
7.5.6 X06: Relays	7.11
7.5.7 X07: Relays	7.11
7.5.8 X08: 3 Phase input	7.11
7.6. Home screen	7.12
7.6.1 Important machine settings for users	7.14
7.7. Menu structure	7.16
7.7.1 Main menu	7.16
7.7.1.1 View	7.16
7.7.1.2 Operation	7.16
7.7.1.3 Fault report	7.17
7.7.1.4 Day report	7.17

Contents	Page No.
7.7.1.5 View service time	7.17
7.7.1.6 View cumulative time	7.17
7.7.1.7 VFD	7.18
7.7.1.8 Rental hours	7.18
7.7.2 Operator	7.18
7.7.2.1 Machine	7.18
7.7.2.2 Operator scheduler	7.19
7.7.2.3 Operator maintenance	7.19
7.7.2.4 Language	7.20
7.7.2.5 VFD control	7.20
7.7.2.6 VFD speed control	7.20
7.7.3 Service	7.21
7.7.3.1 Calibration (offset)	7.22
7.7.3.2 Programmable relay	7.22
7.7.3.3 Temperature	7.22
7.7.3.4 Maintenance	7.22
7.7.3.5 Clock	7.22
7.7.3.6 Digital input	7.22
7.7.3.7 Dryer input	7.23
7.7.3.8 Latitude/Longitude	7.23
7.7.3.9 VFD model	7.23
7.7.4 Customer care	7.23
7.8. Data interface	7.24
7.8.1 Analog output	7.24
7.8.2 DCS port	7.24
7.9. Troubleshooting	7.25
7.10. Construction	7.26
7.10.1 Dimension drawing	7.26
7.11. Example – scheduler setting	7.27
7.12. Revision details	7.28
7.13. Neuron III quick reference	7.29

Dis. Pressure	Discharge pressure
Dis. Temperature	Discharge temperature
HSP	High sump pressure
Temp	Temperature
DPAF	Differential pressure air filter
DPOF	Differential pressure oil filter
AF	Air filter
OF	Oil filter
Min	Minimum
Max	Maximum
VFD	Variable frequency drive
AO	Analog output
UL	Unload
En	Enable
Dis	Disable
L	Load
St	Stop
F	Fault
R	Run
Sby	Standby
STC	Start count
LDC	Load count
DD	Date
MM	Month
YY	Year
Ph Fail	Phase failure
Pr	Pressure
Tr	Temperature
DCS	Distributed control system
PR	Pressure
MMOL	Main motor overload
OL	Overload
NC	Not connected
PS	Pressure schedule
RST	Restart time
DTR	Delta to run
RTS	Run to stop
I/O	Input / Output
REM	Remote
RTU	Remote terminal unit

7.1 Technical specification

Definition	: Pre-programmed logic controller
Function	: Compressor control system & I/O monitoring
Part number	: 018362618
Software	: Embedded C
Rated voltage	: 24VAC + 15% -20%
Power consumption	: 10W (Max)
Ride through	: 30ms
Graphic display	: 2.9" Mono chrome graphics display
Display contrast	: Adjustable using software
Protections	: Low voltage
3 Phase detection	: Phase loss / reverse at the time of pressing START key
Keypad	: 11 key (Usage: up, down, right, left, enter, TAB, INFO, Esc, start, stop & reset) 11 LED (status, warnings and fault indication)
Language	: English, French, Portuguese, Italian, Spanish
Enclosure material	: ABS PC - Plastic
Dimensions	: 280 X 190 X 90 mm
Mounting	: Locking knob for panel tightening
Protection class	: IP55 from front panel only
Operating temp	: - 10°C ~ 50°C (14°F ~ 122°F)
Storage temp	: -10 to 70°C (14°F ~ 158°F)
Relative humidity	: <95% @ 50°C (122°F) without condensation
Certification	: CE, UL

For Technical support/assistance contact ELGI Customer Care
E-mail: ccs@elgi.com

Digital inputs:

Number of channel	: 8 Ports
Rated voltage	: 24VDC
Usage	: Emergency stop, motor overload, cooler over load, motor reverse rotation, DPOF,

Digital outputs:

Number of channel	: 8 Ports
Rated voltage	: 24VDC / 250VAC
Rated load	: 10A @ 250VAC

Coil rated current	: 21mA
Coil voltage	: 24VDC
Contact resistance	: max 100milliohms
Insulation resistance	: min 1000Megohms @ 500VDC
Usage	: 6 Pre-programmed (Main, star, delta, load/unload, ADV, fan motor), 2 by default programmed for trip and warn. programmable for warn, load, service, standby, trip, remote, ready and dryer if enabled.

Analog inputs:

Number of channel	: 4
-------------------	-----

2 x 4-20mA inputs:

Range	: 0 to16 bar (0 to 232 psi)
Resolution	: 0.1bar (1 psi)
Accuracy	: ± 0.1 bar (1 psi)
Usage	: Discharge pressure and sump pressure

2 x PT1000:

Range	: -10 to150° C (14 to 302°F)for 1 st channel -10 to 200° C (14 to 392°F)for 2 nd channel
Resolution	: 1°C (2°F)
Accuracy	: $\pm 1^\circ\text{C}$ (2°F)
Usage	: Discharge temperature, dew point /motor winding temperature software selectable

Analog outputs:

Number of channel	: 2
Range	: 1 to 5V DC
Resolution	: 1 mV
Accuracy	: ± 25 mV
Usage	: Discharge pressure and discharge temperature

Communication ports:

Port 1	: RS485, MODBUS RTU (for DCS interface)
Port 2	: RS485, MODBUS RTU (for VFD parameter reading, analog input module)

7.2.1. Equipment safety

The device, before delivery, was checked according to the prescribed tests of the inspection scheme. In order to maintain this status through shipment and secure a safe operation, consider the notes and warning notes this instruction manual covers. The device should be operated by only trained personnel. Maintenance and repair should be performed only by trained, technical personnel, familiar with the associated dangers. The device can be operated without compromising its security within the certified environment condition.

7.2.1.1. Static discharge warning

This equipment is sensitive to electrostatic discharge, which can cause internal damage and affect normal operation. Follow these guidelines when you handle this equipment:

- Touch a grounded object to discharge potential static.
- Wear an approved grounding wrist-strap.
- Do not touch connectors or pins on component boards.
- Do not touch circuit components inside the equipment.
- Store the equipment in appropriate static-safe packaging when not in use.

7.2.1.2. Assembly

The place of assembly has to correspond to the class of protection. The ambient temperature in the installation position may not exceed the admissible temperature for the nominal use, specified in the data sheet. Not to use in wet condition.

The devices should be installed only outside of explosion hazardous areas!

7.2.1.3. Electrical connection

External connections are to be performed according to the respective national rules. Switch off the device before doing any wiring work. Do not connect or disconnect any wire when the device is powered on and operating.

7.2.1.4. Power supply

It is to be ensured that supply voltage corresponds with the specification on the type sign. If the device is switched on with other devices and/or mechanisms, then the effects have to be considered before switching and appropriate precautions taken. Do not connect welding or such high noise sources to the same line of controller supply.

7.2.2. General instruction

The following procedures and instructions should be followed closely to avoid damage to the control panel and its associated equipment. Reliability of the system depends upon proper installation and maintenance.

The device is to be examined with feed and storage to rule out damage from inappropriate handling. If the device

indicates damage, so that safe operation is not possible, then the device may be removed from operation.

Carefully unpack the system. Open the doors and inspect the cabinet, door, printed circuit board, and other components for the possibility of shipping damage. It is recommended that the cabinet be stored in a clean dry area until mounting takes place.

The signal cables and power cable should be separately routed.

The protective earth connection in the panel must be connected to field earth only.

Protection from direct sunlight

Since the electronic circuits must not be subjected to uncontrolled temperatures, place the cabinet in shade.


Protection from rain

Partial tightening of screws or doors allows water to enter the enclosure and cause irreparable damage to the circuitry. Provide canopy to avoid such damages.

Do not install equipment on structures subject to continuous vibration


Partially tightened wires or components in the cabinet disconnect during vibrations and cause irreparable damage to circuitry.

7.3 Display & terminal details



7.3.1. Terminal connection

- X01 - Power supply
- X02 - Digital input (8 Channel)
- X03 - Analog input (4 Channel) / output (2 Channel)
- X04 - Communication ports (2 Ports)
- X05 - Relay outputs (main, star, delta)
- X06 - Relay outputs (3 Nos)
- X07 - Relay outputs (2 Nos)
- X08 - Phase monitoring



7.4.1. Home screen display

- Easy user interface 8 line graphical display and intuitive menu navigation keys

7.4.2. Records (view -> day report and fault report)

- 30 day reports (load hours, unload hours, run hours, stop hours, fault hours, standby hours, start count, load count)
- 99 fault reports
- Faults with date and time stamp, status of the machine at the time of fault etc.

7.4.3. Remote function (both from MODBUS as well as digital input)

- Remote loading and unloading
- Remote start and stop

7.4.4. Lead and Lag - Pressure schedule (Operator -> schedule)

- 32 pressure program (**one schedule should be in Sunday (first day of the week) 00:00 Hrs**)
- Setting hours considered as 24hr format irrespective of time format setting.
- Important parameters to customize - Day, On Time, OFF Time, Load Pr, Unload Pr

7.4.5. Other interfaces and communication


- VFD interface through MODBUS

- PC interface through MODBUS - To download reports and setting parameters
- 70 + Modbus parameters for DCS controls
- Dryer integration
- High, Low dew point warnings

7.4.6. Safeguard

- The 'Smart Logic' of NEURON III automatically decides the start delay required to ensure minimum wait time between successive starts of the compressor and dryer thereby increasing their lifetime.
- Start Inhibit till sump pressure is within safe limits to enhance the life of the compressor
- Low voltage & Short time Power interrupts detection to enhance the life of the contactors
- Low temperature start inhibit to avoid start-up overloads

7.4.7. Mimic LED for fault indications



LED	Description
Auto	Continuous glow - to indicate the machine in auto power recovery mode. LED blink - when the machine is going to start irrespective of any start mode.
Air oil separator	Glows when 1. Air oil separator service is due - based on service hours 2. Pressure drop in separator is more than set value (if sensor is fixed).
Main motor overload	Glows when the main motor overload digital input is open.
Reverse rotation	Glows when the reverse rotation digital input is closed.
Cooler O/L	Glows when the cooler digital input is open
Pressure	Glows when 1. Analog pressure input is open (probe failure) 2. Discharge pressure is higher than set HSP 3. Sump. pressure is higher than set HSP (If sump pressure sensor is fixed)
Temperature	Glows when the 1. Analog Temperature Input is Open (Probe Failure) 2. Dis. Temperature is higher than set Trip temp.
Differential Pressure oil Filter (DPOF)	Glows when the 1. DPOF Digital input is open & DPOF is enabled 2. Oil filter service is due - based on service hours
Differential pressure air filter (DPAF)	Glows when the 1. DPAF digital input is open & DPAF is enabled 2. Air filter Service is due - based on service hours
Start & Stop	1. Glows in red when machine is stopped / idle 2. Glows in green when machine is running

7.5 Input output description

7.5.1 X01: Power supply

Pin	Function	Id	Active state
1	24V AC Phase	24 VAC P	-
2	24V AC Neutral	24 VAC N	-
3	24V Earth	Earth	-

7.5.2 X02: Digital inputs

Pin	Function	Id	Active state
1	Digital Inputs common - 24VDC	24VDC	-
2	Emergency stop	Emergency	Fault if open
3	Differential pressure oil filter	DPOF	Warn if open
4	Reverse rotation	Rev. Rot	Fault if closed
5	DPAF/REM load and unload	DPAF/REM L/UL	Warn or unload if open
6	Remote start stop control	Remote Start /Stop	Stop if open
7	Dryer warn/trip	Dryer Warn/Trip	Warn/Fault if open
8	Cooler motor overload	Cooler OL	Fault if open
9	Main motor overload	MMOL	Fault if open

7.5.3 X03: Analog input/output

Pin	Function	Id	Type	Range
1 & 3	24V DC discharge pressure	24V DC PR1	4 - 20mA	0 to 16 bar (0 to 232 psi)
2 & 4	24V DC sump pressure	24V DC PR2	4 - 20mA	0 to 16 bar (0 to 232 psi)
5 & 7	Discharge temperature	T1-1 T1-2	PT1000	-10 to 150°C (14 to 302°F)
6 & 8	** Dew point temperature / Ambient temperature/winding temperature	T2-1 T2-2	PT1000	-10 to 200°C (14 to 392°F)
9 & 11	Dis. pressure output (0 to 16 bar/0 to 232 psi) common ground	DAC1 GND	Voltage	1~5V
10 & 12	Dis. Temperature (-10 to 150°C / 14 to 302°F) common ground	DAC2 GND	Voltage	1~5V

7.5.4 X04 : RS 485 Communication

Pin	Function	Id	Active state
2	DCS interface A1	RS485 A	Modbus RTU protocol
4	DCS interface B1	RS485 B	
6	* VFD interface /AI module A2	RS485 A	Modbus RTU protocol
8	* VFD interface /AI module B2	RS485 B	
1	NC		
3	NC		
5	NC		
7	NC		

*If Dryer and VFD is enabled, AI module add-on will be used for dryer dew point

** If Dew point sensor and Winding temperature are used, Winding temperature shall be connected here

7.5.5 X05: Main motor relays

Pin	Function	Id	Active state
1	Common for main, star and delta contactors	Common	-
2	Main contactor	Main	Energized
3	Star contactor	Star	Energized
4	Delta contactor	Delta	Energized

7.5.6 X06 : Relays

Pin	Function	Id	Active state
1	Common - load relay	Common	Load when energized
2	Load relay	L/UL	
3	Common - fan relay	Common	FAN ON when energized
4	Fan relay	NO	
5	Common - auto drain valve relay	Common	ADV ON when energized
6	Auto drain valve relay	NO	


7.5.7 X07 : Relays

Pin	Function	Id	Active state
1	Common - Programmable relay	Common	Energized
2	Programmable relay	NO	
3	Common - Programmable relay	Common	Energized
4	Programmable relay	NO	

7.5.8 X08: 3 Phase input

Pin	Function	Id	Type	Range
1	R Phase	L1	AC Voltage	150 to 550 V AC
2	Y Phase	L2		
3	B Phase	L3		

The home screen will show discharge pressure , discharge oil temperature ,VFD speed % (if VFD enabled), compressor status, warn messages, compressor mode selection details and date & time



Compressor mode selection details:

1. PS - Pressure schedule enabled ,
UL - unload mode enabled,
PS & UL disabled the space will be shown as empty
2. L or R or D - compressor start from - Local or remote or DCS,
3. A or M - Auto restart enabled or auto restart disabled.
For more details refer machine settings in operator menu.

Shortcut key usage

When the controller is in home screen, you can access below listed parameters using the shortcut keys.

"RIGHT" - Live analog values

- Live differential pressure (displays only if sump pressure enabled)

- Live sump pressure (displays only if sump pressure enabled)
- Live Pt1000 temperature (displays only if DRYER ON enabled)

"UP" - Set analog values

- Set load pressure
- Set unload pressure
- Set start sump pressure (displays only if sump Pressure enabled)
- Max differential pressure (displays only if sump Pressure enabled)

"DOWN" - Today report

- Load and stop hours
- Unload and fault hours
- Run and standby hours
- Start count and load count

TAB Key - For changing the language

HELP Key - For contrast adjustments



Message 1 - Compressor status message

Status	Description
Ready	Ready for start
Star	Motor running in star
Run	Motor running in delta
Run load	Compressor in load
Run unload	Compressor in unload
Stop busy	Stop sequence in progress
Emergency stop	Emergency stop push switch is ON
Start inhibit xx.x	During the start, if the sump pressure is higher than the set start sump pressure value, you will see this message. XX.X denotes the live sump pressure value. The compressor starts only if the sump pressure value goes below the set value.
Temperature inhibit ±XX	During the start, if the discharge temperature is lower than the set inhibit temperature value, you will see this message. ±XX denotes the live discharge temperature value. The compressor starts only if the discharge temperature value goes above the set value.
Start inhibit "seconds"	If sump pressure is not used (disabled) then the controller will ensure minimum 60 seconds delay between the stop and the start. Count stops if "STOP" key is pressed
Auto restart "seconds"	If compressor is in auto mode, the controller will ensure minimum delay (user set, e.g. 60 sec) between stop and start. count stops if "STOP" key is pressed
Start ack wait...	This message is displayed after a fault is cleared and waiting for user acknowledgement. By pressing "RESET" key user can acknowledge.
Standby	Compressor in standby

Message 2 - Compressor fault message

Fault	Description
Pr. Probe failure	Discharge pressure sensor probe failure
Tr. Probe failure	Temperature sensor probe failure
Sump pr. probe failure	Sump pressure sensor probe failure, if sump pressure is enabled
HSP (AS)	Case 1: sump pressure is enabled
	If sump pressure exceeds the set high sump pressure value.
HSP (AD)	If discharge pressure exceeds the set high sump pressure value.
Cooler	If the cooler digital Input opens due to Cooler fault
Main motor overload/ VFD error	IF the MMOL digital input opens due to main motor over load. VFD error if VFD control is enabled.
Rev rot / Ph fail	If the rev rot input closes when motor running due to motor reverse rotation or Phase failure.
Trip temperature	If the discharge temperature exceeds the set trip temperature value.
Sump Pressure Not Developing	After the Start, The sump pressure should be at least 0.3 bar/4psi after star delay expires. If this is NOT achieved this Fault occurs , if sump pressure is enabled.
Power failure	If the mains supply is interrupted for more than 20 msec
Low voltage	If the mains supply voltage is less than the 75% of rated voltage. Compressor is tripped & All controller operation is halted until the mains supply Comes back to normal (at least 85% of the rated)
Dis. pressure Not developing	After the Load, The discharge pressure should be at least 0.5 bar/7psi in 5mins. If this is NOT achieved this fault occurs
Dryer IP trip	If dryer is enabled with trip, if dryer trip occurs, this fault message will be shown
Dryer low DP trip	When dew point temperature is less than set value.
Temperature not developing	If the discharge temperature not raised above the inhibit temperature before the set inhibit temperature time.
Winding temp. high	If CV20 variant selected or winding temperature enabled, it will trip the compressor based on SET value of MOTOR WINDING temperature
Winding temp. fail	If CV20 variant selected or winding temperature enabled, it will trip the compressor if sensor open

Message 3 - Compressor warning message

Warning	Description
DPAF	If DPAF Digital Input is Open and DPAF ON in factory setting
DPOF	If DPOF Digital Input is Open and DPOF ON in factory
Dryer Probe Failure	When Ch-4 analog sensor input fails
Dryer Off - Low DP warn	When Ch-4 Dew point temp. is less than Set value
High Dew Point	When Ch-4 Dew point temp. is greater than Set Value
High Differential Pressure	When the difference between Sump. Pressure and Discharge Pressure exceeds the Set Pressure. (Only in Sump Pr. Enabled condition)
Warn Temperature	When Discharge temp. exceeds the set warn temperature (Default is 105Deg C/Deg F)
Change Oil Filter	When service remaining Hr. reaches 0000 Hrs
Change Air Filter	When service remaining Hr. reaches 0000 Hrs
Change Oil	When service remaining Hr. reaches 0000 Hrs
Change Grease	When service remaining Hr. reaches 0000 Hrs
Change Separator	When service remaining Hr. reaches 0000 Hrs
Change Valve kit	When service remaining Hr. reaches 0000 Hrs
Dryer Off - IP Warn	If Dryer Digital Input is Open and dryer warn is selected in the input
Calibration error	When there is error in sensor calibration
Winding temp Exceeded	If CV20 variant selected or winding temperature enabled and if the temperature exceeds [SET value-10] of MOTOR WINDING temperature

7.6.1 Important user machine settings

1. Control mode

Local - Users can start and stop the compressor by using local start/stop key

Remote - Users can start and stop the compressor by using potential free digital input. (refer digital input connector - X04).

DCS - Users can start and stop the compressor by using RS485 modbus communication port (refer connector - X07).

NOTE

In remote and DCS mode, the start/stop button in the controller is inactive. In case of emergency, stop the compressor using the "emergency stop push" button available in the front panel. This is applicable across all types of control mode.

2. Unload mode

If this is enabled, the compressor operates only in unload mode and never in load mode. (This mode is used for service and maintenance purposes.)

3. Auto restart

If this is enabled, the compressor operates automatically after a power outage and resumes based on the previous condition. The default delay is 30* sec. Warn RST delay delays the compressor start if power resumes and Auto Restart Mode is ON.

*If compressor recover from standby, restart delay is 10 sec.

4. Load / Unload pressure

The compressor operates between load pressure and unload pressure based on compressed air utilization. You can set load/unload pressure based on the requirement within the operating pressure band zone.

5. Star delay

Star to delta change over delay time. Default 6 sec delay given in the factory.

6. DTR delay

From delta change over to load delay time. Default 3 sec delay given in the factory.

7. RTS delay

The normal stop of the compressor will unload and wait for this delay time to stop the compressor. The default delay is 5 sec.

8. Standby time

The compressor will switch to standby if unloading exceeds the specified time. The default delay is 5 mins.

Standby resume - If the actual pressure is less than the load pressure, then the compressor will restart automatically after 10 sec delay. If demand from the standby stop comes after 10 sec, the compressor will start

immediately. This feature helps save the energy if very little compressed air is used.

NOTE

If the compressor is started more than the specified number of cycles per hour through the Standby sequence, then the system does not enter into the Standby stop sequence until the existing hour is completed. Next, the Standby override will appear on the screen.

9. Start/Stop per hour

The system will warn if the compressor is started more than the specified number of cycles per hour. The default timeframe is 5 per hours.

10. Auto drain valve

The auto drain valve is a special feature to prevent water from entering into compressed air delivery. This function resets the drain valve to ON and OFF based on the time specified in the menu. The default setting is 5 Sec ON in 4-min intervals. You can adjust the ON and OFF time based on the requirement.

11. Low dew point

The system will warn/trip if the dew point temperature is less than the set value (if the dryer is enabled).

12. High dew Point

The system will warn if the dew point temperature is higher than the set value (if the dryer is enabled).

13. Load/Unload Source

Local: Load/Unload pressure is based on load/unload settings in the controller.

Remote: Selection from digital input- remote load/unload can be operated from remote through a wired switch.

DCS: Load/Unload can be operated from DCS (load/unload command should be given continuously in the interval ≤ 3 sec) Ensure master control bit in enabled condition.

NOTE

The compressor starts working in local load and unload mode if communication is lost in DCS mode.

14. VFD Function

VFD speed percentage will appear in the HOME screen once VFD mode is enabled in the factory setting.

You can also view the below VFD parameters by accessing the view->VFD menu:

- Voltage in V
- Current in A
- Frequency in Hz
- Power in KW
- RPM
- Status of the VFD

VFD Mechanism

- The machine operates at the set minimum speed till it reaches the RUN LOAD condition at start-up.
- The machine will run at the set unload speed when it is in unload, which may be remote or DCS unload or when discharge pressure is > unload pressure.
- The machine will run at optimum speed when optimum is ON. This works only under the load condition. Under the unload condition, it follows the unload speed.
- The machine will run at calculated speed between minimum and maximum speed based on machine usage and when the machine is under load with optimum OFF.

7.7 Menu structure

Press any one of the following keys ▲▼◀ and ▶ to enter main menu

7.7.1 Main Menu

Dis. Pr	: 0.0 bar / 0 psi
Dis. Tr	: 25°C / 77°F
Status	:
	View
	Operator
	Service
	Factory
	Customer care
	Admin

7.7.1.1 View

In the view menu, you can view the set parameters, but you cannot edit any of them - no password required.

View	Operator
	Fault report
	Day report
	Service time
	Cumulative time
	VFD
	Rental hours

7.7.1.2 Operator

LEVEL 1	LEVEL 2	LEVEL 3	LEVEL 4	
View	Operator	Mode	Control mode	Local / Remote / DCS
			Auto restart	On/ Off
			Pressure unit	Bar/psi
			Temperature unit	Fahren / centi
		Pressure	Unload pressure	X X . X b or p (bar or psi)
			Load pressure	X X . X b or p
			Pr. schedule	ON/ OFF
		Delay	Warn RST delay	X X X s (second)
			Star delay	X X s
			DTR delay	X X s
			RTS delay	X X s
			Standby time	X X m (minute)
			St/Sp PH	X X
		DCS port	Type	Modbus
			ID	X X
			Baud	9600/19200
			Parity	None / Even / Odd
			Length	8 / 7
			Stop bit	2 / 1
		Temperature	Trip temperature	X X X C or F
			Warn temp	X X X C or F
			Fan temp	X X X C or F
		Rating	XXXXXXXXXX	
		Fab No.	XXXXXXXXXX	

7.7.1.3 Fault Report

Use Δ and ▽ to select the fault record number (1 to 99). The latest fault will be displayed in the first position. For fault message details refer the "Fault Message" table.

LEVEL 1	LEVEL 2	LEVEL 3
View	Fault report	Fault message
		Date : DD/MM/YY
		Time : HH:MM:SS
		Dis.Pr : X X .X
		Dis.Tr : X X X
		Status : RDY/ACK/STAR etc.,

7.7.1.4 Day Report

The day report explains the usage pattern of the compressor day wise for last 30 days. Use Δ and ▽ to select the record number (1 to 30). The latest report will be displayed in record 1.

LEVEL 1	LEVEL 2	LEVEL 3
View	Day report	Date: DD/MM/YY
		L:X X Hours St: X X Hours
		UL:X X Hours F:X X Hours
		R:X X Hours Sby: X X Hours
		STC:X X X LDC:X X X X X

L- Load, St - Stop, UL - Unload, F- Fault, R- Run, Sby- Standby, STC - Start Count, LDC - Load Count

7.7.1.5 View Service Time

For consumable parts, the remaining life will appear in the view menu. Every run hour, the count will decrements by one hour. Once it reaches zero, an alarm message will pop up and the counter will show negative hours.

LEVEL 1	LEVEL 2	LEVEL 3
View	Service time	Remaining AFCT: X X X X X hours
		Remaining OFCT: X X X X X hours
		Remaining OSCT: X X X X X hours
		Remaining OCT: X X X X X hours
		Remaining RGT: X X X X X hours
		Remaining valve kit: X X X X X hours

7.7.1.6 View Cumulative Time

From the compressor commissioning to till date , the run hours and utilization pattern will be displayed in the menu.

LEVEL 1	LEVEL 2	LEVEL 3
View	Cumulative time	Load X X X X X hrs: X X Min
		Unload X X X X X hrs: X X Min
		Run X X X X X hrs: X X Min
		Stop X X X X X hrs: X X Min
		Fault X X X X X hrs: X X Min
		Standby X X X X X hrs: X X Min
		Start count X X X X X
		Load count X X X X X X X X
		Utilisation X X %

7.7.1.7 VFD

If VFD is enabled in the controller and VFD communication port is connected, you can view the following VFD parameters in Neuron III.

- Voltage in V
- Current in A
- Frequency in Hz
- Power in KW
- RPM
- Status of the VFD
- Run hours based on VFD speed %

< 40% speed	XXXX hours
40~50% speed	XXXX hours
51~60% speed	XXXX hours
61-70% speed	XXXX hours
71-80% speed	XXXX hours
81~90% speed	XXXX hours
91~100% speed	XXXX hours

7.7.1.8 Rental hours

If you select rental hours in the operator menu, you can view the run hours and the utilization pattern of the compressor in the view menu.

To reset the rental hours, you have to choose "rental off" and then "rental on" in operator menu.

Load	X X X X X hrs: X X Min
Unload	X X X X X hrs: X X Min
Run	X X X X X hrs: X X Min
Stop	X X X X X hrs: X X Min
Fault	X X X X X hrs: X X Min
Standby	X X X X X hrs: X X Min
Start count	X X X X X
Load count	X X X X X X X X

7.7.2 Operator

This option requires a password to adjust operator settings within the set limits.

Operator	Machine
	Scheduler
	Maintenance
	Language
	Change password
	VFD control
	Rented hrs setting
	Last serviced

7.7.2.1 Machine

The machine settings available are listed in the below table.

#	Item	Min	Max	Option	Default	Unit
Mode						
1	Control mode	-	-	loc/rem/dcs	loc	-
2	Auto restart	-	-	on / off	off	-
3	Pr unit	-	-	bar / psi	bar/psi	-
4	Tr unit	-	-	cen / far	cen	-
Pressure						
5	Unload pressure	≥ load pressure	≤ max unload pressure	-	Based on compressor pressure rating	bar/psi
6	Load pressure	4.0bar(58psi)	≤ unload pressure -	-		bar/psi
Set Delay						
7	Warn RST	30	250	-	30	second
8	Star	6	20	-	6	second
9	DTR	10	60	-	3	second
10	RTS	5	30	-	5	second
11	Standby	1(VFD),3(Non-VFD)	99	-	3	minute
DCS Port						
12	Type	-	-	Modbus	-	
13	ID	01	99	-	01	-
14	Baud	-	-	9600/19200	9600	bps

#	Item	Min	Max	Option	Default	Unit
14	Baud	-	-	9600/19200	9600	bps
15	Parity	-	-	None/Even/ Odd	None	
16	Length	-	-	8 / 7	8	-
17	Stop bit	-	-	2 / 1	1	-
Auto Drain Valve						
18	Off time	1	180	-	4	minute
19	On time	1	15	-	5	Second
Load / Unload Source						
20	LD / UL Source	-	-	Loc / Rem/ DCS	Loc	-
Set dew point						
21	Low dew point	-6°C(21°F)	2°C(36°F)		-2°C(28°F)	Cen
22	High dew point	6°C(43°F)	12°C(54°F)		8°C(46°F)	Cen
Contrast adjust						
24	Contrast adjust	10	100		50	%

7.7.2.2 Operator - Scheduler

If you enable the pressure scheduler, then you can view and access the below table in edit mode. Use Δ and ∇ to select the pressure scheduler number (1 to 32). For details, refer to "Example - scheduler setting".

#	Item	Min	Max	Option	Default	Unit
1	Day	-	-	Sun to Sat / (--- means no schedule)	---	-
2	Action	-	-	on / off	off	-
3	Time HH	00	23	-	00	Hour
4	Time MM	00	59	-	00	Minute
5	Unload Pressure	\geq Load pressure + 0.5bar(7psi)	\leq Max unload pressure	-	7.5bar (109psi)	bar/psi
6	Load pressure	4.0 bar(58psi)	\leq Unload pressure -	-	5.5bar	bar/psi

(one schedule should be in Sunday (first day of the week) 00:00 Hrs) Then Press "Enter" to set the following

7.7.2.3 Operator - Maintenance

If you modify the settings for the below consumables, you can select the yes option to restart the service counter from the default

#	Item	Min	Max	Option	Default	Unit
1	AF changed	-	-	no/yes	no	-
2	OF changed	-	-	no/yes	no	-
3	OS changed	-	-	no/yes	no	-
4	Oil changed	-	-	no/yes	no	-
5	Re-grease	-	-	no/yes	no	-
6	Valve kit	-	-	No/yes	No	-

7.7.2.4 Language

Default is English. You can choose any one of the given languages.

#	Item
1	English
2	Portuguese
3	Francais
4	Italiano
5	Spanish

7.7.2.5 VFD Control

Item	Min	Max	Default	Unit
Optimum Speed	on/off	on/off	off	
P-Gain	1	50000	250	
I-Gain	1	5000	500	
I-Time	1	200	20	
Max. Speed	Factory settings can be viewed here			RPM
Min. Speed				RPM
Optimum Speed				RPM
UL Speed				RPM
High (5v)				RPM
Low (1v)				RPM

7.7.2.6 VFD Speed Control

Optimum speed: The compressor runs at optimum speed under load with optimum ON (Operator menu).

PI speed control: In the "Run Load" condition, the compressor operates at calculated speed between Min and Max speed depending on air utilization/usage.

Setting the P value

P-Gain - Range: 1-50000. This gain occurs over a full range. The recommended setting is 20-1000.

A proportional-integral controller (PI controller) is a control loop feedback mechanism used in industrial control systems and a variety of other applications requiring continuously modulated control.

Proportional-Integral controller results from the combination of the proportional and the integral mode. This mode is also called as the proportional plus reset action controller

Effect of Proportional Value


The proportional term produces an output value that is proportional to the current error value. The proportional response can be adjusted by multiplying the error by a constant K_p , called the proportional gain constant.

A high proportional gain results in a large change in the output for a given change in the error. If the proportional gain is too high, the system can become unstable. In

contrast, a small gain results in a small output response to a large input error, and a less responsive or less sensitive controller. If the proportional gain is too low, the control action may be too small when responding to system disturbances.

Effect of Integral Value

The contribution from the integral term is proportional to both the magnitude of the error and the duration of the error. The integral term accelerates the movement of the process towards set point and eliminates the residual steady-state error that occurs with a pure proportional controller. However, since the integral term responds to



Parameter	Rise time	Overshoot	Settling time	Steady-state error	Stability
Kp	Decrease	Increase	Small change	Decrease	Degrade
Ki	Decrease	Increase	Increase	Eliminate	Degrade

accumulated errors from the past, it can cause the present value to overshoot the set point value

Effect of change in Kp(Proportional value) & Ki (Integral value) listed below.

Example:

Sample 1:

If P-Gain=20 and the difference between set pressure and actual pressure ≥ 5 bar (73 psi), then the PI loop activates.

Sample 2:

If P-Gain=1000 and the difference between set pressure actual pressure ≥ 0.1 bar (1 psi), then the PI loop activates.

Set a higher P-Gain value if receiver capacity is high and the reverse holds true.

Setting the I-Gain value

I-Gain - Range: 1-5000. This gain occurs over a full range. The recommended setting is 50- 1000.

The recommended value is 125 to 250 in our case. Anything less than 125 will be more stable.

A lower setting enables the system to be tolerant to the error. A value of 50 for I-Gain will enable the system to correct the error only if the pressure difference between set and actual pressure exceeds 0.020 bar / 0.3 psi.

The higher the setting, the more sensitive the system becomes to very small changes.

E.g. A value of 1000 for I-Gain makes the system sensitive to a 0.001 bar / 0.01 psi difference. A very high value and sensitive system (low receiver capacity) will drive the system into a completely unstable state. Always try to set lower values for I-Gain.

Setting I-Time

I-time - Range: 1-200. This indirectly counts the scan time. The recommended value is 15-20.

The higher the value, the more delay will be on the application of correction calculated based on I-Gain and the reverse is true.

Min speed: The compressor remains in min speed up to the start "Run Load" condition during start. If demand is very little, the compressor will run at minimum speed.

Unload speed: The compressor runs at set unload speed during unload. This is irrespective of all unload modes like Remote, DCS and local unload.

Pre-checks that must be performed before starting the compressor under VFD control

- VFD should be enabled in Factory -> VFD settings to

read and write between VFD and Neuron III.

- View the VFD RPM range in the factory AO scaling menu to ensure MODBUS communication exists between VFD and Neuron III. Current VFD RPM appears here, if communication no longer exists.
- Ensure min reference of AO scaling > VFD Parameters 3-02 and 4-11 and max reference of AO scaling < VFD parameters 3-03 and 4-13.

NOTE

The VFD factory settings in the controller are synchronized with VFD. It is not recommended to adjust the settings in VFD.

Rental hrs settings

Rental-ON: If selected, then a separate timer is recorded for rental hrs of load, unload, run, stop, fault, and standby/STC/LDC. It can be viewed in the view menu only when the rental hour is on.

To reset the rental hour, select "rental off" and then "rental on".

Last serviced

AMC service - If you select yes, the last AMC serviced updates with the current date. You can then view it in the customer care menu.

Spares replaced - If you select yes, the last spares replaced updates with the current date. You can then view it in the customer care menu.

Regular service - If you select yes, the Regular service updates with the current date. You can then view it in the customer care menu.

7.7.3 Service

Password required.

The setting changes should be made by ELGi authorized service technicians only. Any attempt to change service settings by unauthorized people may lead to compressor malfunction and the warranty becoming void.

Service	Sensor Offset
	Relay
	Temperature
	Maintenance
	Clock
	Self-Test
	Password
	Digital Input
	Dryer Input
	Unload Mode
	Lat /Lon
	VFD_model

7.7.3.1 Calibration (offset)

If any deviation occurs in the pressure and temperature between that displayed in the controller and that in the master gauge, approach the ELGI service engineer.

7.7.3.2 Programmable relay

Select programmable relay 1 or 2 using the Δ and ∇ keys. Then press "Enter" to assign any one of the following functionalities to the relay.

#	Item
1	Warn
2	Load
3	Service
4	Stand by
5	Trip
6	Remote
7	Ready

Default

Relay 1 = Warn
Relay 2 = Trip

NOTE

If Dryer is enabled, then programmable relay 2 is not user programmable. It is used for automatic dryer control.

7.7.3.3 Temperature

Fan Temperature - Fan relay will energize if discharge temperature reaches the set value. It will de-energize when the temperature comes below 75°C from the set value. Alternatively, fan start/stop is allowed for 15 times/ per hour. Beyond 15 times, the fan will not switch off.

The above logic will work only if the fan input connected to relay output of the controller (Ref:7.5.6 X06: Relay in page No:7.11).

Inhibit temperature - If you enable this setting and Temperature inhibit is already enabled in factory settings, the compressor will start when the discharge temperature is higher than the set value.

Temperature inhibit time - The compressor will wait for this specified time to reach the inhibit temperature. If not, it trips as temperature is not building. .

#	Item	Min	Max	Option	Default	Unit
1	Fan temp	On 95°C	Off	-	-	C/F
2	Inhibit temp	-5°C (23°F)	5°C (41°F)	-	0°C (32°F)	C/F
3	Tr_ initial time	5	90	-	5	min

7.7.3.4 Maintenance

Here you can feed the filter lift time. This timeframe will vary depending on the model and filter. Contact Elgi for more information.

You used to register the filter replacement in operator-> Maintenance by choosing Yes/No option. Once you choose Yes in operator then filter life time will be updated.

#	Item	Min	Max	Option	Default	Unit
1	Set AFCT	0000	30000	-	2000H	Hour
2	Set OFCT	0000	30000	-	2000H	Hour
3	Set OSCT	0000	30000	-	4000H	Hour
4	Set OCT	0000	30000	-	2000H	Hour
5	Set RGT	0000	30000	-	2000H	Hour
6	Set Valve Kit	0000	30000	-	2000H	Hour

7.7.3.5 Clock

Here the real time clock settings can be done. 24 hrs format will be applicable for all menus and features related to clock settings, Whereas 12 hrs time format is applicable for the home screen only.

#	Item	Min	Max
1	Hour	00	23
2	Minute	00	59
3	Second	00	59
4	Date	01	31
5	Month	01	12
6	Year	00	99
7	Day	Sun/Mon/Tue/Wed/Thu/ Fri/Sat	

Daylight saving

Daylight saving settings will add 1 or 2 hours from the current GMT time. If you choose daylight option as off, the clock will revert back to GMT time.

#	Item	Min	Max
1	Date format	DD/MM/YY	MM/DD/YY
2	Time format	12 hr	24 hr
3	Day light savings	0	2

7.7.3.6 Digital input

Configuration of DI-4 (DPAF or Remote Load/Unload) can be viewed from this menu. (if the load/unload source is selected as remote in operator -> machine settings). Then the digital Input will configure for remote Load/Unload.

7.7.3.7 Dryer input

Dryer digital input DI-6 can be configured for warn or trip. This input will be effective if the dryer is ON in factory -> dryer.

7.7.3.8 Latitude/Longitude

This option involves deg, min, and sec with NE, NW, SE, and SW format.

The Latitude/Longitude entry helps ELGi to determine the location of the compressor on which air alert is equipped.

7.7.3.9 VFD_model

A list of VFD models appears here for you to select a pressure-based speed, based on customer requirement.

7.7.4 Customer care

Dis. Pr	:	6.0 bar/ 87psi
Dis. Tr	:	32°C (90°F)
Status	:	S/W Version
URL	:	www.elgi.com
E-mail	:	ccs@elgi.com

Neuron III supports two types of data interface

- Analog output
- DCS Port

7.8.1 Analog output

Two channels are available as analog output.

Channel -1 for discharge pressure values 0.0 to 16.0 bar / 0 to 232 psi converted into 1 to 5V.

Channel -2 for discharge temperature values from -10 to 150°C / 14 to 302°F converted into 1 to 5V.

NOTE

If analog input probe failure occurs, analog output becomes 0V by default.

7.8.2 DCS port

The DCS port is a Modbus RTU type to interface to the generic DCS system.

You can set the device ID in the "Operator/ Machine/ DCS Port" menu. Also the baud rate, parity, data length, and stop bit are user settable.


7.9 Troubleshooting

S. NO	Failure symptoms	Possible causes	Remedies
1	No display in LCD Screen & Backlight was not glown	No input supply	Check incoming AC input
		Transformer failure.	Please check the controller input voltage at connector X08. Voltage should be 24V \pm 15% VAC.
		Controller failure.	Change the controller.
2	Key not functioning Note: Controller keys	Key not responding	Check any key stuck / Flat. If any change Controller
		Key struck / Flat	Change the controller.
3	"Low voltage" message in display.	Controller Input voltage less than 18VAC	Until will start functioning, once input voltage recovered to nominal or with in specification (415 V +10% - 15 %)
4	"Pr. probe failure" message in display	Loose connection in connector position (X03 - 1, 3) & (X03 - 2, 4) .	Check the loose connection at both end - Controller and pressure sensor side.
		Pressure sensor failure.	Change the Pressure sensor.
		Controller failure	Check the voltage across (X03 - 3) & (X03-4) with Gnd, voltage should be b/w 0.4 to 2VDC. If it is different change the controller.
5	"Tr. probe failure" message in display	Loose connection in connector position (X03 - 5, 7) & (X03 - 6, 8)	Check the loose connection at both end - Controller and Temp sensor side.
		Temperature sensor failure.	Change the Temperature sensor.
		Controller failure	Check the voltage across (X03 - 7) & (X03-8) with Gnd, voltage should be 3.3 VDC. If it is different change the controller.
6	"Emergency stop" "MMOL" "Cooler OL" "Dryer trip" "Rev rot/Ph fail" message in display	Loose connection in connector position X02 - 1 to 9).	Check the loose connection at controller end.
		Switch got struck	Check either the external switches got sturck / Fault not cleared
		Controller failure	Change the controller.
7	Motor not driving	Controller failure	Disconnect the X05, X06 & X07 connector, Check the relay working by switching on the start key (X05 -1) with (X05- 2, 3 & 4) & (X06 -1) with (X06-2). Note: Ccheck in the continuity mode.
8	"Phase loss/ Reverse" message in display	Loose connection in connector position X08 - 1, 2 & 3.	Check the loose connection at controllor end.
		Controller failure	Check for the X05 connection X08(1- R, 2-Y, 3 -B), Still the same error change the controller

7.10 Construction

- Plastic enclosures
- IP55 polyethylene front keypad
- Inputs and Outputs through terminal block
- Enclosure dimensions 280 X 190 X 90 mm

7.10.1 Dimension drawing




7.11 Example – scheduler setting

Scheduler settings are considered when:

1. End customer usage is 6 bar (87 psi)
2. Pressure variation in the air pipe is less than 0.1bar (1 psi)
3. All 3 compressors connect to a single/common header or a common receiver
4. All 3 compressors connect to a common header or a common receiver

Pressure schedule settings in Neuron III												
	Comp-1				Comp-2				Comp-3			
	ON	OFF	Load bar (psi)	U/L bar (psi)	ON	OFF	Load bar (psi)	U/L bar (psi)	ON	OFF	Load bar (psi)	U/L bar (psi)
Monday	Lead				Lag				Lag			
	8:00	18:00	7 (102)	7.5 (109)	8:00	18:00	6.6 (96)	7.2 (104)	8:00	18:00	6 (87)	6.8 (99)
Tuesday	Lag				Lead				Lag			
	8:00	18:00	6 (87)	6.8 (99)	8:00	18:00	7 (102)	7.5 (109)	8:00	18:00	6.6 (96)	7.2 (104)
Wednesday	Lag				Lag				Lead			
	8:00	18:00	6.6 (96)	7.2 (104)	8:00	18:00	6 (87)	6.8 (99)	8:00	18:00	7 (102)	7.5 (109)
Thursday	Lead				Lag				Lag			
	8:00	18:00	7 (102)	7.5 (109)	8:00	18:00	6.6 (96)	7.2 (104)	8:00	18:00	6 (87)	6.8 (99)
Friday	Lag				Lead				Lag			
	8:00	18:00	6 (87)	6.8 (99)	8:00	18:00	7 (102)	7.5 (109)	8:00	18:00	6.6 (96)	7.2 (104)
Saturday	Lag				Lag				Lead			
	8:00	18:00	6.6 (96)	7.2 (104)	8:00	18:00	6 (87)	6.8 (99)	8:00	18:00	7 (102)	7.5 (109)
Sunday	00:00hrs As required ON/Off has to be set. This is mandatory setting.											



Example - scheduler setting


Weekly utilization

Comp ->	Air demand: 100%			Air demand: 75%			Air demand: 50%			Air demand: 25%		
	C1	C2	C3	C1	C2	C3	C1	C2	C3	C1	C2	C3
Day-1	100	100	100	100	100	25	100	50	0	75	0	0
Day-2	100	100	100	25	100	100	0	100	50	0	75	0
Day-3	100	100	100	100	25	100	50	0	100	0	0	75
Day-4	100	100	100	100	100	25	100	50	0	75	0	0
Day-5	100	100	100	25	100	100	0	100	50	0	75	0
Day-6	100	100	100	100	25	100	50	0	100	0	0	75
Avg. Utl%	100	100	100	75	75	75	50	50	50	25	25	25

Conclusion

Equal utilization of all the 3 compressor based on pressure demand

The scheduler reduces power consumption since compressors are only utilized based on demand.



Neuron III Pressure schedule setup

Step-1 Go to operator menu

Step-2 Enter password "4545"

Step-3 operator -> schedule

Step-4 enable

Step-5 set ON TIME

Step-6 set OFF TIME


Step-7 set load Pr.

Step-8 set unload Pr.

7.12 Revision Details

Version	Date	Changes
1.0	25/02/15	Release
2.0	09/05/15	Updated corrections
3.0	30/06/17	Software features & CE/UL updated
3.1	01/03/18	Software version 2.07
3.2	01/12/18	Software version 2.08
3.3	11/03/19	Software version 2.09
3.4	05/07/19	Software version 2.09a
3.5	10/02/20	Software version 2.09b
3.6	10/07/20	Software version 2.09c

7.13 Neuron III quick reference



- 1 128x64 Graphical display
- 2 Navigation keys
- 3 Enter key
- 4 Start key
- 5 LED (green - start , red - stop/fault)
- 6 Stop key
- 7 Reset key
- 8 Oil filter change indication LED
- 9 Air oil separator change indication LED
- 10 Cooler fault LED
- 11 Auto mode enabled indication LED
- 12 High pressure fault LED
- 13 Main motor fault LED
- 14 Reverse rotation fault LED
- 15 Air filter change indication LED
- 16 High discharge temperature fault LED
- 17 Escape key
- 18 Tab key
- 19 Info key

MAIN SCREEN DISPLAY

- Package Discharge Pressure
- Discharge Temperature
- VFD Speed % on screen (if applicable)
- Machine Status like Run, Load, Unload, Standby etc.
- Warning Messages
- Date & Time
- Mode Information (see below)

Mode Information – 1, 2, 3

1. PS – Pressure Schedule Enabled / UL – Unload Mode Enabled
2. L – Local / R – Remote / D – DCS

MAIN SCREEN SHORTCUTS

Pressing the navigation keys while on the main menu allows user to read common settings.

►“RIGHT” - Live Analog Values

1. Live Differential Pressure (Displays only if Sump Pressure enabled)
2. Live Sump Pressure (Displays only if Sump Pressure enabled)
3. Live Pt1000 Temperature (Displays only if Dryer ON enabled)

▲ “UP” – Set Analog Values

1. Current Load Pressure
2. Current Unload Pressure
3. Current Start Sump Pressure (Displays only if Sump Pressure enabled)
4. Current Differential Pressure (Displays only if Sump Pressure enabled)

▼ “DOWN” – Today Report

1. Load and Stop Hours
2. Unload and Fault Hours
3. Run and Standby Hours

Compressor Status messages

Status	Description
Ready	Ready for start
Star	Motor running in star
Run	Motor running in delta
Run load	Compressor in load
Run unload	Compressor in unload
Stop busy	Stop sequence in progress
Emergency stop	Emergency stop push switch is ON
Start inhibit xx.x	During the start, if the sump pressure is higher than the set start sump pressure value, you will see this message. XX.X denotes the live sump pressure value. The compressor starts only if the sump pressure value goes below the set value.
Temperature inhibit ±XX	During the start, if the discharge temperature is lower than the set inhibit temperature value, you will see this message. ±XX denotes the live discharge temperature value. The compressor starts only if the discharge temperature value goes above the set value.
Start inhibit "seconds"	If sump pressure is not used (disabled) then the controller will ensure minimum 60 seconds delay between the stop and the start. Count stops if "STOP" key is pressed
Auto restart "seconds"	If compressor is in auto mode, the controller will ensure minimum delay (user set, e.g. 60 sec) between stop and start. count stops if "STOP" key is pressed
Start ack wait...	This message is displayed after a fault is cleared and waiting for user acknowledgement. By pressing "RESET" key user can acknowledge.
Standby	Compressor in standby

Compressor Warning messages

Warning	Description
DPAF	If DPAF Digital Input is Open and DPAF ON in factory setting
DPOF	If DPOF Digital Input is Open and DPOF ON in factory
Dryer Probe Failure	When Ch-4 analog sensor input fails
Dryer Off - Low DP warn	When Ch-4 Dew point temp. is less than Set value
High Dew Point	When Ch-4 Dew point temp. is greater than Set Value
High Differential Pressure	When the difference between Sump. Pressure and Discharge Pressure exceeds the Set Pressure. (Only in Sump Pr. Enabled condition)
Warn Temperature	When Discharge temp. exceeds the set warn temperature (Default is 105Deg C/Deg F)
Change Oil Filter	When service remaining Hr. reaches 0000 Hrs
Change Air Filter	When service remaining Hr. reaches 0000 Hrs
Change Oil	When service remaining Hr. reaches 0000 Hrs
Change Grease	When service remaining Hr. reaches 0000 Hrs
Change Separator	When service remaining Hr. reaches 0000 Hrs
Change Valve kit	When service remaining Hr. reaches 0000 Hrs
Dryer Off - IP Warn	If Dryer Digital Input is Open and dryer warn is selected in the input
Calibration error	When there is error in sensor calibration

Compressor Fault messages

Fault	Description
Pr. Probe failure	Discharge pressure sensor probe failure
Tr. Probe failure	Temperature sensor probe failure
Sump pr. probe failure	Sump pressure sensor probe failure, if sump pressure is enabled
HSP (AS)	Case 1: sump pressure is enabled
	If sump pressure exceeds the set high sump pressure value.
HSP (AD)	If discharge pressure exceeds the set high sump pressure value.
Cooler	If the cooler digital Input opens due to Cooler fault
Main motor overload/ VFD error	IF the MMOL digital input opens due to main motor over load. VFD error if VFD control is enabled.
Rev rot / Ph fail	If the rev rot input closes when motor running due to motor reverse rotation or Phase failure.
Trip temperature	If the discharge temperature exceeds the set trip temperature value.
Sump Pressure Not Developing	After the Start, The sump pressure should be at least 0.3 bar/4psi after star delay expires. If this is NOT achieved this Fault occurs , if sump pressure is enabled.
Power failure	If the mains supply is interrupted for more than 20 msec
Low voltage	If the mains supply voltage is less than the 75% of rated voltage. Compressor is tripped & All controller operation is halted until the mains supply Comes back to normal (at least 85% of the rated)
Dis. pressure Not developing	After the Load, The discharge pressure should be at least 0.5 bar/7psi in 5mins. If this is NOT achieved this fault occurs
Dryer IP trip	If dryer is enabled with trip, if dryer trip occurs, this fault message will be shown
Dryer low DP trip	When dew point temperature is less than set value.
Temperature not developing	If the discharge temperature not raised above the inhibit temperature before the set inhibit temperature time.
Winding temp. high/fail	It will trip the compressor based on SET value of MOTOR WINDING temperature/ sensor open

Menu Structure

