



SUPERVISOR CONTROLLER™

INSTRUCTION MANUAL ALL MODELS

**OPERATOR'S
MANUAL**

**KEEP FOR
FUTURE
REFERENCE**

Part Number

02250146-049

©Sullair Corporation

AIR CARE SEMINAR TRAINING

Sullair Air Care Seminars are 3-day courses that provide hands-on instruction in the proper operation, maintenance and service of Sullair equipment. Individual seminars on Industrial compressors and compressor electrical systems are presented at regular intervals throughout the year at a dedicated training facility at Sullair's corporate headquarters in Michigan City, Indiana.

Instruction includes discussion of the function and installation of Sullair service parts, troubleshooting of the most common problems, and actual equipment operation. The seminars are recommended for maintenance and service personnel.

For detailed course outlines, schedule and cost information contact:

Sullair Corporate Training Department

1-888-SULLAIR or
219-879-5451 (ext. 5363)
www.sullair.com

- Or Write -

Sullair Corporation

3700 E. Michigan Blvd.
Michigan City, IN 46360
Attn: Service Training Department

TABLE OF CONTENTS

OPERATOR IS REQUIRED TO READ
ENTIRE INSTRUCTION MANUAL



Section 1 SAFETY

	page
1	1.1 GENERAL
1	1.2 ELECTRIC SHOCK
1	1.3 VARIABLE SPEED DRIVE
1	1.4 DECALS

Section 2 SUPERVISOR DESCRIPTION

5	2.1 SUPERVISOR KEYBOARD LAYOUT
5	2.2 MAIN DISPLAY
5	2.3 FUNCTION MENU
6	2.4 STATUS- CURRENT PRESSURES, TEMPERATURES, INPUTS AND OUTPUTS
6	2.5 CONTROL PARAMETERS- PRESSURE, TEMPERATURE AND TIMER SETTINGS
7	2.6 MAINTENANCE- PREVENTIVE MAINTENANCE INFORMATION AND TIMERS
7	2.7 FAULT LOG- LOG OF PREVIOUS FAULTS
7	2.8 SENSOR LOG
7	2.9 SEQUENCING- SEQUENCING & COMMUNICATION PARAMETERS
8	2.10 SYSTEM DISPLAY- DISPLAY OF MODES OF MACHINES IN A SEQUENCING SYSTEM
8	2.11 CALIBRATION- CORRECTION FACTORS FOR PRESSURES
10	Table 2-1 Supervisor Controller Menu Tree

Section 3 START-UP PROCEDURES

11	3.1 MOTOR ROTATION DIRECTION CHECK
11	3.2 INITIAL START-UP PROCEDURE
11	3.3 SUBSEQUENT START-UP PROCEDURE
11	3.4 SHUTDOWN PROCEDURE

TABLE OF CONTENTS

Section 4	page	
TROUBLESHOOTING	13	4.1 TROUBLESHOOTING INTRODUCTION
	13	4.2 TROUBLESHOOTING GUIDE- SUPERVISOR CONTROLLER
	16	Table 4-1A Analog Alarms (Flooded Screw Compressors Less Than 200 psi)
	17	Table 4-1B Analog Alarms (LS-16T, LS-20T and LS-20TS Compressors)
	18	Table 4-2 Parameters
	19	4.3 MACHINE BEHAVIOR AFTER A POWER OUTAGE
	19	4.4 REMOTE STOP/START INPUT
	19	4.5 BROWN OUT INPUT
	19	Table 4-3 Machine Power Outage Behavior
	19	Table 4-4 Remote Start/Stop Input
Section 5		
WIRING SCHEMATIC DIAGRAMS	21	5.1 WIRING DIAGRAM- SUPERVISOR COMMUNICATION MODULE
	22	5.2 WIRING DIAGRAM- SUPERVISOR CONTROL
Section 6		
VARIABLE SPEED DRIVE	23	6.1 SAFETY
	23	6.2 OVERVIEW
	24	Table 6-1: Cable and Fuse Sizes- 460V Ratings
	24	6.3 INSTALLATION
	24	6.4 SUPERVISOR DISPLAY AND MENUS
	24	6.1.1 VSD STATUS
	25	6.4.2 CONTROL PARAMETERS
	25	6.4.3 CALIBRATION
	25	6.4.4 FACTORY SETUP
	25	6.4.5 VSD SETUP
	26	6.5 STARTUP OF NEW COMPRESSOR PACKAGE
	26	6.6 FAULT AND WARNING CODES

Section 1

SAFETY

1.1 GENERAL

Sullair Corporation and its subsidiaries design and manufacture all of their products so they can be operated safely. However, the responsibility for safe operation rests with those who use and maintain these products. For safe machine operation it is vitally important to review all safety precautions noted in the Safety Section of your compressor's Operator's Manual. The precautions listed there, as well as those following, are offered as a guide which, if conscientiously followed, will minimize the possibility of accidents throughout the useful life of this equipment.

The compressor should be operated only by those who have been trained and delegated to do so, and who have read and understood their compressor's Operator's Manual. Failure to follow the instructions, procedures and safety precautions listed here and in the Operator's Manual may result in accidents and injuries.

NEVER start the compressor unless it is safe to do so. **DO NOT** attempt to operate the compressor with a known unsafe condition. Tag the compressor and render it inoperative by disconnecting and locking out all power at source or otherwise disabling its prime mover so others who may not know of the unsafe condition cannot attempt to operate it until the condition is corrected.

Use and operate the air compressor only in full compliance with all pertinent OSHA requirements or

any pertinent Federal, State, and Local codes or requirements.

DO NOT modify the compressor and/or controls in any way except with written factory approval.

1.2 ELECTRICAL SHOCK

A. Keep all parts of the body and any hand-held tools or other conductive objects away from exposed live parts of electrical system. Maintain dry footing, stand on insulating surfaces and **DO NOT** contact any other portion of the compressor when making adjustments or repairs to exposed live parts of the electrical system.

B. Attempt repairs only in clean, dry and well lighted and ventilated areas.

C. Stay clear of the compressor during electrical storms! It can attract lightning.

1.3 VARIABLE SPEED DRIVE

Refer to Section 6 for safety information on products with variable speed drives.

1.4 DECALS

See Figures 1-1A and 1-1B. The Supervisor control panel contains several decals which contain necessary information for safe performance. These decals should never be removed. If a decal becomes damaged, contact your nearest Sullair Distributor or the Sullair Corporation factory Service Department for replacement parts (Note: When ordering new decals, use part number printed on decal face.).

Section 1

SAFETY

Figure 1-1A Decals

⚠ WARNING



This Unit Is Equipped With An Auto Start Sequence That Will Start The Unit In The Event Of A Power Failure Automatically After The Sump Pressure Drops To 10 PSIG And The Power Is Restored.

When Performing Maintenance Follow Your Company's Prescribed Safety Practices for Electrical Equipment.

250017-903

⚠ DANGER



Death or serious injury can occur from inhaling compressed air without using proper safety equipment.

See OSHA standards on safety equipment.

250027-935

⚠ WARNING



Do not permit air from this equipment to contact food stuff except in full compliance with FDA Standard 21CFR178.3570, and all other applicable federal, state and local, codes, standards and regulations.

250003-144

CAUTION: This machine is equipped with Automatic Stop / Start Control System.

DO NOT ATTEMPT to make any adjustment without disconnecting both main line and control circuit electrical power.

41065

Section 1 SAFETY

Figure 1-1B Decals


<i>key number</i>	<i>description</i>	<i>part number</i>	<i>quantity</i>
1	decal, warning auto start	250017-903	1
2	decal, danger breath air (I)	250027-935	1
3	sign, warning "food grade" lube	250003-144	1
4	decal, auto start	041065	1

(I) OSHA and FDA guidelines are superseded by any Federal, State or Local regulations whenever applicable.

Section 2

SUPERVISOR DESCRIPTION

Figure 2-1 Supervisor Control Panel



SUPERVISOR DESCRIPTION

2.1 SUPERVISOR KEYBOARD LAYOUT

Refer to Figure 2-1. The Display module has eleven keys grouped in two rows.

The top row has the following seven keys :

 - Help key, used to display possible causes of and correction for an alarm or fault.

 - Returns to main display.

 - Used to edit text or numbers (move cursor left).

 - Used to edit text or numbers (move cursor right).

 - Used to change numbers or text, or scroll.

 - Used to change numbers or text, or scroll.

 - Used to select an item from a menu, or start and end an edit on a parameter.

The bottom row has four keys :

 - Stop, stops machine. Clears faults and warnings if machine is stopped.

 - Run, starts machine. Clears warnings if machine is running.

 - Toggles auto mode.

 - Toggles Local/Remote mode. This can be used to disable sequencing.

2.2 MAIN DISPLAY

Line 1 - Machine state :

E-Stop - E- Stop button pressed, or auxiliary e-stop present.

Stopped - Machine not running.

Unloaded - Machine running unloaded.

Loaded - Machine running, loaded and modulating.

Full Load - Machine forced to full load. (Used only in sequencing modes).

Remote Stop - Compressor is off but armed to start. The machine will start when the remote start contact is closed. **NOTE** : the machine may start at any time.

Seq Stop - Compressor is off but armed to start. The machine will start when the sequencing conditions meet the criteria to start. **NOTE**: the machine may start at any time.

Trim - Machine running, loaded and modulating in a sequenced system.

Line 2 - Fault or Warning, blank means no fault or warning is present.

If there are multiple alarms, they will be shown for 2 seconds each. If an alarm is active, pressing the '?' key will give troubleshooting information on that alarm.

Line 3 - P2 - Line pressure

Line 4 - T1 - Discharge Temperature

2.3 FUNCTION MENU

While in the main display, if any of the arrow keys are pressed, the function menu is displayed. This menu is used to view status or edit parameters.

The function menu has the following entries :

Status - Current pressures, temperatures, inputs and outputs.

VSD Status - (VSD packages only) See Section 6.

Control Parameters - Pressure and temperature and timer settings.

Maintenance - Preventive maintenance information and timers.

Fault Log - Log of previous faults.

Sensor Log - Log of sensor readings leading up to a fault.

Sequencing - Sequencing parameters.

System Display - Display of modes of machines in a sequencing system.

Calibration - Correction factors for pressures.

Test - Used by Sullair personnel for troubleshooting serial communications.

Factory Setup - Model settings.

VSD Setup - (VSD Packages only) See Section 6.

To select a function, use the up and down arrow keys to scroll to the desired function as indicated on

last line of display, then press the enter  key.

After entering a function, the information can be viewed by using the up and down arrow keys. If the function shows status then values cannot be changed. If the function displays parameters, then the values can be changed.

To change a value, scroll to the line to be changed

Section 2

SUPERVISOR DESCRIPTION

using the up arrow and down arrow keys, and push the enter button. The value can be changed by using the up arrow or down arrow keys. When editing is finished, pushing the enter key will fix the value. If during a change the ESC key is pushed, editing is terminated and the original value is reset.

The left and right arrow keys can be used to move to other digits or letters in a value. For example to change a value from 100 to 500, the left arrow key can be used to position the cursor to the 1 digit in the 100, and the up arrow key used to increment the digit to 5.

Text fields can also be edited in the same manner. Push the enter key to start the edit, use the left and right arrow keys to move to the letter to be changed, then use the up and down arrow to change the letter. Push the enter key to complete the edit.

The following are detailed descriptions of the various displays.

2.4 STATUS - CURRENT PRESSURES, TEMPERATURES, INPUTS AND OUTPUTS

All inputs and outputs are displayed showing both the designator and the description (eg. T1-Discharge) along with the selected temperature (C or F) or pressure (psi, bar, kPa) units. Digital inputs and outputs are shown either as a '0' (zero) or '1' (one). Zero is off and one is on. This is a view only display.

The order of display is :

Temperatures - T1 through T5 depending on model.

Pressures - P1 through P4 depending on model.

Delta pressures - dp1 through dp3 depending on model.

Load Hours - Hours machine has run loaded.

Run Hours - Hours machine has run loaded or unloaded.

Load Cycles - Number of load/unload cycles.

Starts - Number of times machine has started.

E-Stop String - E-Stop push button.

Aux E-Stop - Auxiliary E-Stop, wired by customer.

Digital Inputs - D1 through D10, depending on model.

Relay Outputs - K1 through K8, depending on model.

2.5 CONTROL PARAMETERS - PRESSURE, TEMPERATURE AND TIMER SETTINGS

Parameters that control the operation of the

machine are viewed and set using this display. These parameters may vary by machine model.

The Control Parameters are :

Unload pressure - The pressure where the machine is unloaded. For example if this parameter is set to 110 psi (7.6 bar) the machine will unload when the line pressure is above 110 psi (7.6 bar).

Load delta - The pressure differential below the unload pressure where the machine is loaded. For example if the unload pressure is set to 110 psi (7.6 bar) and the load differential is set to 10 psid (0.7 bar), the machine will load when the line pressure goes below 100 psi (6.9 bar).

Setpoint - (VSD packages only) The targeted pressure for the variable speed controls. This is normally adjusted near the bottom of the load/unload band above. The speed will be adjusted to maintain this pressure. Refer to Section 6 for additional details.

Unload Time - If the machine is running in AUTO mode, this parameter specifies the amount of time that the machine will run unloaded before shutting off. If the time is set less than 15 minutes (for example 5), there may be times when the machine will run unloaded for more than 15 minutes. This is because there is another timer that keeps the machine from being started more than four times an hour. This secondary timer is disabled when a machine is configured for VSD motor control.

Drain Interval - If the machine has an electric solenoid drain, this parameter and the following parameter (Drain Time) are used to turn on the drain. The interval is the time between activations of the drain and the Drain Time is the length of the time energized. This does not apply to the Sullair SCD zero loss drain, which is not controlled or monitored by the Supervisor.

Drain Time - Length of time that drain is energized.

Restart time -

WARNING

Enabling this function also enables automatic restart after power recovery. Be sure to depress the Emergency Stop button to defeat this function when automatic start is to be prevented.

Time to wait after power up before starting machine. This parameter is used to keep several machines from starting at the same time after power up, or to delay start until other equipment is started. If disabled parameter is zero, the machine will not automatically start after power up. If this parameter is a

SUPERVISOR DESCRIPTION

number larger than zero, the machine restarts after a delay defined by this time. For example, if the Restart Time is set to 10 seconds, then the machine will be enabled to start after 10 seconds.

Wye to delta transition timer - Also used to control the closed inlet start valve. Disable by setting to zero (0), standard for full voltage start. Requires approximately 4-6 seconds for wye-delta or solid state starting.

Modulate - Default state is Yes for normal machine control. Select No for Load/No Load operation.

NOTE

Unload pressure **MUST** be lowered to rated pressure when using Load/No Load mode.

Language select - English, German, Spanish, Italian and French may be selected for display language.

Temp Units - Temperature units may be set to degrees F or degrees C.

Press Units - Pressure units may be set to psi, bar, or kPa.

(VSD packages only) - Additional adjustments for VSD operation are shown in Section 6.

2.6 MAINTENANCE - PREVENTIVE MAINTENANCE INFORMATION AND TIMERS

The following lines are on the Maintenance display.

Information - The top two lines may be changed to advise what to do when there is a maintenance warning. For example a distributor can put in his name and telephone number.

Ser. No - Serial number of machine.

Warn at - When the following drop below this number, a warning is issued.

Oil Filter hours - Hours before oil filter change.

PN - Oil Filter part number.

Separator hours - Hours before separator change.

Prim. - Primary separator part number.

Sec. - Secondary separator part number.

Air Filter hours - Hours before air filter change.

Prim. - Primary air filter part number.

Sec. - Secondary air filter part number.

Oil hours - Hours before oil change.

PN - Oil part number.

Oil Anal. - Hours before oil analysis.

These hours and part numbers can be changed using the enter and arrow keys.

2.7 FAULT LOG - LOG OF PREVIOUS FAULTS

The fault log shows the last 16 faults that occurred. The top line of the display shows the run hours where the fault occurred, and the second line shows the fault. The faults can be scrolled through using the up and down arrow keys. They are ordered by most recent first. (ie. when the function is entered the most recent fault is displayed. Pressing the down arrow displays the previous fault etc).

2.8 SENSOR LOG

Log of sensor readings leading up to a fault.

The sensor log shows the sensor readings leading up to a fault. The top line shows the last fault. The following lines show T1, T2, P1 & P2. Each line represents readings that are 5 seconds apart for one minute, then one minute apart for 10 minutes. There is a second set of readings for T3, T4, P3 & P4.

2.9 SEQUENCING - SEQUENCING & COMMUNICATION PARAMETERS

The following parameters can be viewed and edited. For more details on sequencing see the Supervisor Sequencing and Protocol Manual.

Sequence By - Sequencing mode can be set to:

Disabled - Control does not do any sequencing.

Remote - Enables Remote Start/Stop, Remote Load/Unload and Local/Master inputs

Hours - Uses the Seq Hrs parameter to determine order of sequencing

Number - Uses the Com Number to determine order of sequencing

Seq Hrs - This is an hour counter used when the 'Sequence By' parameter is set to 'Hours'. Each hour that the machine is running increments this counter. When then 'Sequence By' parameter is set to 'Hours', the machine with the least amount of Seq Hrs is started first, and the machine with the most Seq Hrs is shut off first.

Com Number - Communications number. When two or more machines are connected together using the network (RS-485 channel), each machine must have a unique number or address. These must be assigned in numerical order. For example in a three machine system the machine communications numbers should be 1, 2 & 3.

Machines - This is the total number of machines

Section 2

SUPERVISOR DESCRIPTION

connected to the network (RS-485 channel). For example in a three machine system, this parameter should be set to 3. Up to sixteen machines may be networked if all have Supervisor Controllers and limited to eight if some have Supervisor II's.

Low Press - This is the lowest pressure allowed before immediately starting a machine.

Recovery Time - This parameter keeps multiple machines from loading, unloading and starting at the same time. For example if a low pressure condition causes a machine to start, the next machine will not start unless the Recovery Time has elapsed, and the pressure has not recovered (i.e., has risen over 'Low Press').

Rotate - This parameter is used only in very special cases.

The only time this parameter should be used is in a

NOTE

Leave this parameter disabled unless instructed by Sullair Service Personnel.

situation where, once a machine is started, it never stops (ie. the unload timer never expires). This can happen when the load matches the output of the machine, all the time. In this case the machine will never unload and shut off. The rotate forces the machine to stop after it's Seq Hrs. are greater than the other machines. For example in a two machine system, with Rotate set at 100 hrs. The machine that is running will shut off when the Seq Hrs. are 100 more than the machine that is stopped.

Minute, Hour, Day, Month, Year- If the Communications Module is present in the system, the time and date can be set using these parameters.

2.10 SYSTEM DISPLAY - DISPLAY OF MODES OF MACHINES IN A SEQUENCING SYSTEM

Note that this display is only applicable when there are two or more machines connected to the communications network (RS-485) and the Sequence By parameters on each machine are set to 'Hours' or 'Number'.

The columns are described below

Communication Number

Status -

- E - Emergency Stop
- M - Manual stop
- R - Remote stop
- B - Standby

- S - Starting
- U - Unloaded
- L - Loaded
- T - Trim machine
- F - Full load

Sequencing Hours

Capacity - Not used at this time.

Local System Pressure - Pressure read by machines pressure transducer.

The top line is a legend that describes each column. The right hand number on the top line is the system pressure. The system pressure is the highest pressure reading of all the machines. Note that the local pressure readings can be used to determine what machines may need to be calibrated. The system pressure transducers on all machines should read within 1(one) psi of one another. The calibration function can be used to set the readings to be the same.

2.11 CALIBRATION - CORRECTION FACTORS FOR PRESSURES

The first line of this display is the password. If the password is 0 then the following parameters are not protected and can be changed. If the password is non-zero, then enter the displayed number plus 4 to enable changing the parameters. For example if the number displayed is 10 then changing the password to 14 will enable editing.

The four pressures P1, P2, P3 & P4 as well as the differential pressure dP1 can be calibrated. The number on the right hand side of the line is added to the transducer reading to give the calibrated reading. The calibrated reading is shown in the middle of the line.

Cap and KW calibration (VSD packages only) may be used to adjust values shown on VSD Status displays. These are factory set to nominal values (100%), but may be adjusted as desired.

There are also three other parameters in the calibration function:

Protect - When set to yes, protects the control parameters from change.

Fault on Warn - Force fault on warning.

Force Unload - When set to yes, forces the machine to unload.

2.12 TEST- Used by Sullair personnel for troubleshooting of serial communications.

2.13 FACTORY SETUP- Model settings.

The factory setup display is used by Sullair personnel to initially set up the machine. The following val-

SUPERVISOR DESCRIPTION

ues reflect the machine configuration.

Model - Model number of machine.

Cooling - Air or Water.

Press Trans - Pressure transducer range 200, 250, 500.

P1 Max - Maximum discharge pressure.

KT Fluid - Yes or No, indicating fluid.

Water Switch - Water pressure switch, Yes or No.

Oil Switch - Oil pressure differential switch, Yes or No.

Min Load Psi - Minimum acceptable load P1 pressure setting. Separator Maintenance warning is disabled for loaded P1 pressures below this value (i.e., during start-up).

Lube Cycle - Pre-lube/ Post-lube function timer - 0 seconds (disabled) to 30 seconds.

K8 Option - K8 output relay function selector - Disabled, Oil pump prelube and postlube control, Master Control for special external sequence control.

Stop Timer - Time to run machine before stopping.

Protect - Protect control parameters.

Load Hours - Hours machine was running and loaded.

Run Hours - Hours machine was running loaded and unloaded.

Load Cycles - Number of load/unload cycles.

Starts - Number of machine starts.

Capacity - Maximum capacity of machine.

Spiral Valve - (VSD packages only) Yes or No, indicating spiral valve control.

VSD- Describes signal from Supervisor controls to the VSD controls:

None - No VSD

Pressure - The Supervisor pressure signal is connected to a drive analog input

Serial - The drive is connected on the Supervisor serial data bus


Speed - The Supervisor provides a speed signal to a drive analog input.

Com Module - Yes/No Enables or disables the communication module if installed.

Mtr Module - Yes/No Enables or disables the motor actuator module if installed.

Section 2 SUPERVISOR DESCRIPTION

Table 2-1 Supervisor Controller Menu Tree



* These parameters do not apply to some models.

START-UP PROCEDURES

3.1 MOTOR ROTATION DIRECTION CHECK

After the electrical wiring has been done, it is necessary to check the direction of the motor rotation. With the control system in MANUAL mode, press the  and  pads in succession to bump start the compressor. When looking at the motor from the end opposite the compressor unit, the shaft should be turning clockwise on all gear driven models, and counterclockwise on direct drive models. If the motor shaft is not turning in the proper direction, disconnect the power to the starter and exchange any two of the three power input leads, then recheck rotation. A "Direction of Rotation" decal is located on the coupling guard between the motor and compressor to show proper motor/compressor rotation.

Variable speed drive packages will have main motor direction set at the time of construction, but the fan direction is affected by installation. If fan-cooled, ensure that fan rotation is correct. To change direction, disconnect the power and exchange any two of the three fan motor leads at the fan motor starter.

3.2 INITIAL START-UP PROCEDURE

The following procedure should be used to make the initial start-up of the compressor.

1. Be sure that all preparations and checks described in the Installation Section have been made.
2. Read the preceding pages of this manual thoroughly.
3. Jog motor to check for correct rotation of fan (refer to Section 3.1).

4. Start the compressor in the desired operating mode  or .
5. Slowly open the shut-off valve to the service line.
6. Check for possible leaks in piping.
7. Slowly close the shut-off valve to assure proper nameplate pressure unload setting is correct. The compressor will unload at nameplate pressure. If adjustments are necessary, see Control System Adjustment section in the compressor operator's manual.
8. Observe the operating temperature. Refer to compressor operator's manual for acceptable operating range. If temperature exceeds this range, the cooling system and installation environment should be checked.
9. Open shut-off valve to the service line.
10. Reinspect the compressor for temperature and leaks the following day.

3.3 SUBSEQUENT START-UP PROCEDURE

On subsequent start-ups, check that the proper level is visible in the fluid sight glass and simply press the START  or AUTO MODE  button. When the compressor is running, observe the instrument panel and maintenance indicators.

3.4 SHUTDOWN PROCEDURE

To shut the compressor down, simply press the STOP  button.

NOTES

Section 4

TROUBLESHOOTING

4.1 TROUBLESHOOTING INTRODUCTION

NOTE

Whereas Sections 4.1 and 4.2 portray common systematic setbacks that can occur during controller operation, for a more thoroughly in-depth coverage of machine operation setbacks, consult the Troubleshooting Section in the machine's operator's manual.

The information contained in the Troubleshooting chart has been compiled from factory experience. It contains symptoms and usual causes for the described problems. However, **DO NOT** assume that these are the only problems that may occur. All available data concerning the trouble should be systematically analyzed before undertaking any

repairs or component replacement procedures.

A detailed visual inspection is worth performing for almost all problems and may avoid unnecessary additional damage to the compressor. Always remember to:

- a. Check for loose wiring.
- b. Check for damaged piping.
- c. Check for parts damaged by heat or an electrical short circuit, usually apparent by discoloration or a burnt odor.

Should your problem persist after making the recommended check, consult your nearest Sullair Distributor or the Sullair Corporation factory Service Department.

4.2 TROUBLESHOOTING GUIDE- SUPERVISOR CONTROLLER

MESSAGE	MODEL	ENABLE	PROBABLE CAUSE	REMEDY
Air Filter Maint	ALL	ALWAYS	Differential Pressure Across Inlet Filter High	Replace filter.
	ALL	ALWAYS		Check inlet filter pressure switch.
Aux Motor Overload	ALL	ALWAYS	Auxiliary Motor Tripped on Cooling Fan, Oil Pump or Other Motor	Reset auxiliary overload after heater element cools. Verify correct motor amps.
	ALL	ALWAYS		Check for loose connections.
	ALL	ALWAYS		Check motor starter contact for proper operation.
	ALL	ALWAYS		Check line voltage, if low consult power company.
E-Stop	ALL	ALWAYS	E-Stop Button Active	Release button.
E-Stop Push Button	ALL	ALWAYS		Check wiring.
E-Stop String	ALL	ALWAYS	Auxiliary E-Stop String Open	Check auxiliary E-Stop devices.
	ALL	ALWAYS		Check wiring.
Low Water Pressure	ALL	Watercooled	Cooling Water Pressure Below 10 psi (0.7bar)	Check for closed valves or broken pipes.
Oil Change Due, Oil Filter Change, Separator Change Due, Air Filter Change, Oil Analysis Due, Maintenance Due	ALL	ALWAYS	Maintenance Due	Select Maintenance from menu to see service due and part numbers.
Main Motor Overload	ALL	ALWAYS	Main Motor Overload	Reset overload after heater element cools down.
	ALL	ALWAYS		Make sure compressor is properly configured.
	ALL	ALWAYS		Make sure load pressure is set below limit of compressor.

Continued...

Section 4

TROUBLESHOOTING

4.2 TROUBLESHOOTING GUIDE- SUPERVISOR CONTROLLER (CONTINUED)

MESSAGE	MODEL	ENABLE	PROBABLE CAUSE	REMEDY
Main Motor Overload (CONTINUED)	ALL	ALWAYS	Main Motor Overload (cont.)	Check motor starter contacts for proper operation.
	ALL	ALWAYS		Check line voltage, if low consult power company.
I/O Mod Com Error, Com Mod Com Error, Motor Mod Com Error, VSD Com Error	ALL	ALWAYS	Module Network Error; The Network that Connects the Display Module, I/O Module and Other Optional Modules is Not Working Correctly	Check wiring.
	ALL	ALWAYS		Replace module referred to in error message, if problem persists replace display module.
Oil Filter Maint., dP2 Oil Filter High	ALL	ALWAYS	Pressure Across Oil Filter Above 20 psi (1.4 bar) While Running	Oil filter clogged, replace oil filter.
	FLOODED	ALWAYS		Low ambient temperature, sump heater may be required in ambients below 40°F (4°C).
	ALL	ALWAYS		Sensor failure, check sensor, wiring and tubing.
P3 Oil Pressure Low, dP3 Oil Pressure Low	ALL	ALWAYS	Oil Pressure Low	Oil pump failure, consult Sullair service department.
	ALL	ALWAYS		Oil filter clogged; replace oil filter.
	FLOODED	ALWAYS		Sump oil level low, replenish oil to proper level.
	FLOODED	ALWAYS		Low ambient temperature, sump heater may be required in ambients below 40°F (4°C).
	FLOODED	ALWAYS		Oil pump may be required for remote coolers.
P1 Sensor Fail, P2 Sensor Fail, P3 Sensor Fail, P4 Sensor Fail, T1 Sensor Fail, T2 Sensor Fail, T3 Sensor Fail, T4 Sensor Fail, T5 Sensor Fail	ALL	ALWAYS	Sensor or Wiring Failure	Check sensor wiring. Check sensor.
dP1 Separator High	FLOODED	ALWAYS	Pressure Across Separator High	Plugged separator elements, replace. Pressure sensor failure, check sensor wiring.
Factory Setup Error	ALL	ALWAYS	The Factory Setup Information Needs to be Reviewed for Correct Values	If problem persists replace Supervisor.
P1 Sump Pressure High	FLOODED	ALWAYS	Sump Pressure High (Poppet, Sullicon, Spiral, Blowdown or Pneumatic Valve Failed)	Check valves. Check Sullicon adjustment (see Control Adjustment section in the compressor operator's manual).

Continued...

Section 4

TROUBLESHOOTING

4.2 TROUBLESHOOTING GUIDE- SUPERVISOR CONTROLLER (CONTINUED)

MESSAGE	MODEL	ENABLE	PROBABLE CAUSE	REMEDY
P1 Sump Pressure High (CONTINUED)	FLOODED	ALWAYS	Sump Pressure High (Poppet, Sullicon, Spiral or Blowdown, or Pneumatic Valve Failed) (cont.)	Solenoid valves, check operation and wiring.
	ALL	ALWAYS		Pressure regulator, check adjustment and operation.
	FLOODED	ALWAYS		Check minimum pressure check valve (not applicable to Oil Free compressors).
P1 Sump Pressure Low	FLOODED	ALWAYS	Sump Pressure Low	Check pressure sensor, wiring and tubing.
	FLOODED	ALWAYS		Machine may have failed to start.
T1 Interstage High, T2 Discharge High, T3 Oil Temp High, T4 Intercool High, T5 Discharge High, T1 Discharge High, T2 Dry Side High, T3 Oil Temp High, T4 Interstage High	ALL	ALWAYS	High Temp. Fault	Ambient above 105°F (41°C), improve local ventilation.
	FLOODED	ALWAYS		Fluid level low, replenish to proper level.
	FLOODED	ALWAYS		Thermal valve, check operation.
	ALL	Aircooled		Cooler fins dirty, clean fins and fan.
	ALL	Watercooled		Low water flow, check for valve closed, pump off or broken pipe. High water temperature, increase flow or lower water temperature.
	ALL	Watercooled		
	ALL	Watercooled		Cooler plugged, clean tubes and shell, if plugging persists, use cleaner water.
Power Interruption	ALL	ALWAYS	Motor Starter(s) Not Working	Check starter controls and wiring.
			No Contact to Input D8	Check wiring to input.
			Intermittent Control Power	Check line voltage and connections.
VSD Emergency Stop	ALL	VSD	E-Stop Button Active	Release button.
VSD Com Fault	ALL	VSD	Communication Error Detected by Drive	Check for intermittent control wiring to drive.
VSD Param Lim Fault	ALL	VSD	Communication Error at Power-up or Setup	Check control wiring to drive.
			Incorrect Factory or VSD Setup	Check setup menus and drive rating.
VSD Drive Fault__	ALL	VSD	Fault Detected by Drive	See Section 6.

Section 4

TROUBLESHOOTING

Table 4-1A Analog Alarms (Flooded Screw Compressors Less Than 200 psi)

Sensor	Type	Limit	Start Delay	Run Delay	Check (*)	Comment
P_1	High Inhibit	5	0	0	At Start	High sump psi at start
P_1	Low Fault	5	5	0	When Running	Immediate Fault
P_1	High Fault	500	0	0	Constantly	Sensor failure fault
P_2	High Fault	500	0	0	Constantly	Sensor failure fault
P_3	High Fault	500	0	0	Constantly	Sensor failure fault
P_4	High Fault	500	0	0	Constantly	Sensor failure fault
T_1	Low Fault	-40	0	0	Constantly	Sensor failure fault
T_1	High Warn	225	5	30	Constantly	Delayed for temp spikes
T_1	High Fault	235	5	30	Constantly	Delayed for temp spikes
T_1	High Warn	245	0	0	Constantly	Immediate Warning
T_1	High Fault	255	0	0	Constantly	Immediate Fault
T_1	High Fault	500	0	0	Constantly	Sensor failure fault
T_2	Low Fault	-40	0	0	Constantly	Sensor failure fault
T_2	High Warn	225	5	30	Constantly	Delayed for temp spikes
T_2	High Fault	235	5	30	Constantly	Delayed for temp spikes
T_3	Low Warn	-40	0	0	Constantly	Sensor failure warning
T_3	High Warn	500	0	0	Constantly	Sensor failure warning
T_4	Low Fault	-40	0	0	Constantly	Sensor failure fault
T_4	High Fault	500	0	0	Constantly	Sensor failure fault

(*) In the 'Check' column above, alarms are checked:

Constantly - if machine running or stopped

When Running - if machine is running

If Enabled - if parameter is non-zero

At Start - will not allow start if alarm present

Over Min Psi - machine is loaded and above min load pressure

Section 4

TROUBLESHOOTING

Table 4-1B Analog Alarms (LS-16T, LS-20T and LS-20TS Compressors)

Sensor	Type	Limit	Start Delay	Run Delay	Check (*)	Comment
P_1	Low Fault	5	5	0	When Running	Immediate Fault
P_1	High Inhibit	5	0	0	At Start	High sump psi at start
P_1	High Fault	500**	0	0	Constantly	Sensor failure fault
P_2	High Fault	500**	0	0	Constantly	Sensor failure fault
P_3	High Fault	500**	0	0	Constantly	Sensor failure fault
P_4	High Fault	500**	0	0	Constantly	Sensor failure fault
T_1	Low Fault	-40	0	0	Constantly	Sensor failure fault
T_1	High Warn	245	5	30	Constantly	Delayed for temp spikes
T_1	High Warn	255	0	0	Constantly	Immediate Warning
T_1	High Fault	255	5	30	Constantly	Delayed for temp spikes
T_1	High Fault	265	0	0	Constantly	Immediate Fault
T_1	High Fault	500	0	0	Constantly	Sensor failure fault
T_2	Low Fault	-40	0	0	Constantly	Sensor failure fault
T_2	High Warn	245	5	30	Constantly	Delayed for temp spikes
T_2	High Warn	255	0	0	Constantly	Immediate Warning
T_2	High Fault	255	5	30	Constantly	Delayed for temp spikes
T_2	High Fault	265	0	0	Constantly	Immediate Fault
T_2	High Fault	500	0	0	Constantly	Sensor failure fault
T_3	Low Warn	-40	0	0	Constantly	Sensor failure warning
T_3	High Warn	500	0	0	Constantly	Sensor failure warning
T_4	Low Fault	-40	0	0	Constantly	Sensor failure fault
T_4	High Warn	245	5	30	Constantly	Delayed for temp spikes
T_4	High Warn	255	0	0	Constantly	Immediate Warning
T_4	High Fault	255	5	30	Constantly	Delayed for temp spikes
T_4	High Fault	265	0	0	Constantly	Immediate Fault
T_4	High Fault	500	0	0	Constantly	Sensor failure fault

(*) In the 'Check' column above, alarms are checked:

Constantly - if machine running or stopped

When Running - if machine is running

If Enabled - if parameter is non-zero

At Start - will not allow start if alarm present

Over Min Psi - machine is loaded and above min load pressure

(**) 750 psi for 750 psi transducers.

Section 4

TROUBLESHOOTING

Table 4-2 Parameters

Type	Enable	Default	Min	Max	Display Text	Comment
Setup	Always	1	0	2	Press Trans	200,250,500, 750
Setup	X200	135	50	225	P1 Max	250psi transducer
Setup	X250	135	50	195	P1 Max	200psi transducer
Setup	X500	250	150	495	P1 Max	500psi transducer
Setup	X750	400	300	560	P1 Max	750psi transducer
Setup	Always	0	0	1	Water Switch	Water pressure switch enable for water cooled machines
Setup	Flooded	0	0	1	Oil Switch	Oil switch enable for flooded screw machines
Setup	Always	65	20	200	Min Load Psi	Minimum acceptable Loaded P1 value
Setup	Always	0	0	30	Stop Timer	If not 0, run unloaded for this time before stopping
Setup	Always	0	0	30	Lube Cycle	Prelube/Postlube timer
Setup	Always	0	0	2	K8 Option	Disable, Lube Pump, Master Control
Setup	Always	0	0	100000	Load Hours	Hours machine has been loaded
Setup	Always	0	0	100000	Run Hours	Hours machine has been running
Setup	Always	0	0	100000	Load Cycles	Number of load cycles
Setup	Always	0	0	100000	Starts	Number of starts
Setup	Always	0	0	10000	Capacity	Used by monitor to determine system load
Cal	Always	0	-7	7	P1	
Cal	Always	0	-7	7	P2	
Cal	Always	0	-20	10	dP1	
Cal	Always	0	-7	7	P3	
Cal	Always	0	-7	7	P4	
Cal	Always	0	0	1	Fault on Warn	Force shutdown on warning
User	X200	110	30	220	Unload	250psi transducer unload pressure
User	X250	110	30	185	Unload	200psi transducer unload pressure
User	X500	150	150	360	Unload	500psi transducer unload pressure
User	X750	150	150	560	Unload	750psi transducer unload pressure
User	Always	10	3	70	Load Delta	Differential pressure from unload pressure
User	Always	15	0	59	Unload Time	Auto mode shut down after unloaded for this time
User	Always	0	0	30	Drain Interval	Time between drains (Minutes)
User	Always	0	0	10	Drain Time	Duration of drain (Seconds)
User	Always	0	0	59	Restart Time	Auto restart on power up if not 0 (Seconds)
User	Always	0	0	15	Wye Delta	Wye to delta starter transition time (Seconds)
User	Always	0	0	2	Language	French, German, Italian, Spanish, English
User	Always	0	0	1	Temp Units	Fahrenheit, Celsius
User	Always	0	0	2	Press Units	Pressure units, Psi, Bar, kPa
Seq	Com Mod	0	0	4	Sequence by	Disabled,Com, Hours, Remote, Slave, Time Of Day etc.
Seq	Always	0	0	100000	Seq Hrs	Used for Hours sequencing mode
Seq	Always	1	1	16	Com Number	Communications ID number
Seq	Always	1	1	16	Machines	Number of machines in a system
Seq	Always	70	20	185	Low Press	Panic start next machine in sequence
Seq	Always	10	2	59	Recover Time	Keeps multiple machines from starting at same time (seconds)
Seq	Always	0	0	250	Rotate	Used to force a machine to stop

4.3 MACHINE BEHAVIOR AFTER A POWER OUT-AGE

Condition: Machine was in a running or ready condition when power was lost. Table 4-3 below describes how a machine behaves after a power up under various conditions if the Restart timer is greater than 0. If the Restart timer is 0 the machine powers up in the Manual Stop state.

The Seq. Mode column pertains to the Sequencing mode parameter. It can be Disabled, set to Remote Start/Stop or to other sequencing modes (Seq). The Local/Remote column refers to the Local/Remote Button on the display panel. The Remote Start/Stop column pertains to the Remote Start/Stop input. The Run Mode column the machine run mode (Auto button on the display panel). Note that this table only applies if the Restart Timer has a value other than zero. If the Restart Timer is zero then the machine always powers up in Manual Stop.

4.4 REMOTE STOP/START INPUT

Table 4-4 below describes how a machine reacts to

the Remote Start/Stop input. See previous table for column descriptions.

NOTE

the Sequencing Mode parameter must be set to Remote to enable Remote Start/Stop input.

4.5 BROWN OUT INPUT

Normally not wired by factory, this feature is used to enable the compressor to properly recover from very short-cycle power loss or voltage dips for those installations that are susceptible to this kind of power interruption. The controller alone is not as sensitive to these interruptions as is the switchgear, and must be told that the loss has occurred.

A normally closed starter contact wired to the Brownout input (D8) forces the controller into a standby state if the starter drops out. The controller will then re-engage the starter after normal start permissives are satisfied.

Table 4-3 Machine Power Outage Behavior

Seq. Mode	Local/Remote	Remote Start/Stop	Run Mode	Action (State)
Disabled	xxxx	xxxx	Cont	Manual Stop
Disabled	xxxx	xxxx	Auto	Start after Restart delay & P2 < Load psi, & P1 < 5 psig
Remote	Local	xxxx	Cont	Manual Stop
Remote	Local	xxxx	Auto	Start after Restart delay & P2 < Load psi, & P1 < 5 psig
Remote	Remote	Off	Cont	Remote Stop
Remote	Remote	Off	Auto	Remote Stop
Remote	Remote	On	Cont	Start after Restart delay
Remote	Remote	On	Auto	Start after Restart delay & P2 < Load psi, & P1 < 5 psig

Note: 'xxxx' means 'has no effect'.


Table 4-4 Remote Start/Stop Input

Local/Remote	Remote Start/Stop	Run Mode	Action (State)
Local	xxxx	Cont	Normal Cont Operation
Local	xxxx	Auto	Normal Auto Operation
Remote	Off	Cont	Remote Stop
Remote	Off	Auto	Remote Stop
Remote	On	Cont	Start if stopped
Remote	On	Auto	Normal Auto Operation

NOTES

WIRING SCHEMATIC DIAGRAMS

5.1 WIRING DIAGRAM- SUPERVISOR COMMUNICATION MODULE



02250131-248R01

VARIABLE SPEED DRIVE

6.1 SAFETY

The following special instructions apply to VSD packages provided with electronic adjustable speed motor drives. These are in addition to other warnings and cautions.

WARNING

Ground the unit following the instructions in this manual. Ungrounded units may cause electric shock and/or fire. The variable speed drive has a large capacitive leakage current during operation, which can cause enclosure parts to be above ground potential. Proper grounding, as described in this manual, is required. Failure to observe this precaution could result in death or severe injury.

WARNING

Before applying power to the variable speed drive, make sure that the front and cable covers are closed and fastened to prevent exposure to potential electrical fault conditions. Failure to observe this precaution could result in death or severe injury.

WARNING

Refer all drive service to trained technicians. This equipment should be installed, adjusted, and serviced by qualified electrical maintenance personnel familiar with the construction and operation of this type of equipment and the hazards involved and in accordance with published service manuals. Failure to observe this precaution could result in death or severe injury.

WARNING

Line terminals (L1, L2, L3), motor terminals (U, V, W) and the DClink/brake resistor terminals (-/+) are live when the drive is connected to power, even if the motor is not running. Contact with this voltage is extremely dangerous and may cause death or severe injury.

WARNING

Before opening the variable speed drive covers:

- Disconnect all power to the variable speed drive.
- Wait a minimum of 5 (five) minutes after all the lights on the keypad are off. This allows time for the DC bus capacitors to discharge.
- A hazard voltage may still remain in the DC bus capacitors even if the power has been turned off. Confirm that the capacitors have fully discharged by measuring their voltage using a multimeter set to measure DC voltage. Failure to follow the above precautions may cause death or severe injury.

CAUTION

Do not perform any meggar or voltage withstand tests on any part of the variable speed drive or its components. Improper testing may result in damage. Prior to any tests or measurements of the motor or the motor cable, disconnect the motor cable at the variable speed drive output terminals (U, V, W) to avoid damaging the variable speed drive during motor or cable testing.

CAUTION

Do not touch any components on the circuit boards. Static voltage discharge may damage the components.

CAUTION

Install the variable speed drive in a well-ventilated room that is not subject to temperature extremes, high humidity, or condensation, and avoid locations that are directly exposed to sunlight, or have high concentrations of dust, corrosive gas, explosive gas, inflammable gas, grinding fluid mist, etc. Improper installation may result in a fire hazard.

CAUTION

Make sure that no power correction capacitors are connected to the variable speed drive output or the motor terminals to prevent variable speed drive malfunction and potential damage.

CAUTION

Make sure that the variable speed drive output terminals (U, V, W) are not connected to the utility line power as severe damage to the variable speed drive may occur.

6.2 OVERVIEW

The Sullair VSD drive application is custom designed for operation of air compressors. All necessary control functions are performed through the Supervisor keypad. The drive functions as a module on the Supervisor communications bus.

Relevant drive status data and compressor performance are presented on the Supervisor display. Its keypad provides simple setup and adjustment of necessary drive parameters. Drive controls are coordinated with internal compressor controls, and with other Supervisor compressors in sequenced systems. The Supervisor monitors drive performance to provide motor thermal and other protections in an easy-to-use, robust design.

Section 6

VARIABLE SPEED DRIVE

Table 6-1: Cable and Fuse Sizes - 460V Ratings

_ UL recognized type RK.

_ Based on a maximum environment of 104°F (40°C).

hp	Size (A)	Fuse (A)	Wire Size Power	Wire Size Ground
40	61	80	2	8
50	72	100	2	6
60	87	110	1	6
75	105	125	1/0	2
100	140	175	3/0	2
125	170	200	4/0	2
150	205	250	350MCM	1/0
200	261	350	2 x 250MCM	1/0

NOTE ON ELECTRICAL PREPARATION:

Interior electrical wiring is performed at the factory. Required customer wiring is minimal, but should be done by a qualified electrician in compliance with OSHA, National Electrical Code, and/or any other applicable State, Federal and local electrical codes concerning isolation switches, fused disconnects, etc. Sullair provides a wiring diagram for use by the installer.

NOTE

Customer must provide electrical supply power disconnect within sight of machine.

6.3 INSTALLATION

This variable speed AC drive has been properly mounted, adjusted, and tested prior to shipment of the compressor package. Inspect the unit to ensure it was not damaged during shipment. The package provides a terminal block for connection of three-phase power and ground. Refer to the package wiring diagram for specific connection information. All internal wiring to the drive and motors has been provided by the factory, in accordance with the drive's requirements. Do not alter factory wiring. To ensure proper wiring to the package, use the following guidelines:

- Use heat-resistant copper cables only, +75°C or higher.
- The minimum input line cable and line fuses must be sized in accordance with the rated input current of the unit. See Table 6-1.
- Consistent with UL listing requirements, for maximum protection of the variable speed drive, use UL recognized fuses, type RK5.
- Suitable for circuits delivering fault currents up to 100,000A.

6.4 SUPERVISOR DISPLAY AND MENUS

Refer to Section 2 for a general description of the Supervisor and its displays and adjustments. This

section addresses special functions applicable to VSD packages.

6.4.1. VSD STATUS

This group of displays shows the performance of the variable speed compressor package. The following may be used for evaluation of system performance. The first four lines indicate real-time conditions:

Capacity - Delivery in CFM.

Capacity % - Percent of full package capacity.

Power - Total package power in KW.

Power % - Percent of power at full capacity.

The next eight lines indicate recent longer-term performance. See Section 6.4.2 for reset procedure.

Capacity - Average delivery in CFM.

Capacity % - Average percent of full package capacity.

Power - Average total package power in KW.

Power % - Average percent of power at full capacity.

KCF - Running total of air delivered in thousands of cubic feet.

VARIABLE SPEED DRIVE

KWH - Running total of energy used in kilowatt-hours.

Cost - Running total of cost of operation.

Savings - Estimated savings compared to other control methods.

The next eight lines indicate long-term performance during the entire life of the compressor.

Capacity - Average delivery in CFM.

Capacity % - Average percent of full package capacity.

Power - Average total package power in KW.

Power % - Average percent of power at full capacity.

KCF - Running total of air delivered in thousands of cubic feet.

KWH - Running total of energy used in kilowatt-hours.

Cost - Running total of cost of operation.

Savings - Estimated savings compared to other control methods.

The last five lines indicate real-time control system parameters for service evaluation.

P2 - System pressure.

Motor RPM - Motor speed.

Frequency - Output frequency of the drive in Hertz.

Drive Temp - Internal temperature of the drive.

Motor Prot - Estimated percentage of motor temperature rise.

6.4.2 CONTROL PARAMETERS

The following adjustments apply specifically to VSD packages.

Setpoint - The targeted pressure for the variable speed controls. This is normally adjusted near the bottom of the load/unload band above. The speed will be adjusted to maintain this pressure. Most packages will allow adjustment of this over a wide range, to allow tailoring to the needs of the application. Adjustments will be automatically made to the maximum speed to operate the motor at its full capacity at any pressure.

Cost/KWH - The cost per kilowatt-hour of energy is entered here, for use in cost estimates in the VSD Status displays. For example, enter 0.070 for 7 cents per KWH.

Saving vs - The basis for savings estimates. The cost of VSD operation can be compared to Inlet modulation, Load/Unload, or variable displacement

(spiral valve) control systems.

Reset Load Est. - This resets the "Recent Usage" values to zero in the VSD Status calculations. This functions similarly to a trip odometer in a car.

6.4.3 CALIBRATION

Two additional calibration adjustments are provided in VSD. These can be used to fine tune nominal values used in VSD Status displays. Each is adjustable from 0 to 200% of nominal.

Cap - for adjustment of delivery values. This may be used for adjustment to actual conditions, or for display in other units of measure.

KW - This may be used for adjustment to calibrated meters under actual operating conditions.

6.4.4 FACTORY SETUP

Factory adjustments are generally the same as conventional packages, with a few additions.

Model - The features in this section apply only to V120, V160, V200, V200S, and V200TS models. These packages are designed specifically for integrated drive control. This model selection will affect the choices available in the VSD Setup group.

Capacity - This number will be adjusted, along with maximum speed, whenever a change is made to the setpoint pressure.

Spiral Valve - This should be set as appropriate for the package. The spiral valve will be closed for highest efficiency at all moderate to heavy demands. The valve will be opened for light demands.

VSD - The descriptions in this section apply only to packages with integrated drive controls operating in serial communications with the Supervisor.

6.4.5 VSD SETUP

This group of adjustments sets up the parameters of the drive for the construction of the compressor package. These may be viewed at any time, but are protected by the password in the Factory Setup group.

VSD Auto-Set - This should be set to "Yes" for all normal applications. This performs automatic adjustment of several parameters based on operating conditions and user adjustments.

Nominal HP - The nameplate horsepower of the main drive motor.

Nominal Volts - The compressor package rated nominal voltage

VSD Max Amps - The rated maximum current of the drive

Section 6

VARIABLE SPEED DRIVE

Motor FLA - The motor's rated full load amps at nominal HP⁽¹⁾

Motor SF - The motor's nameplate service factor

Motor V - The motor's rated voltage⁽¹⁾

Motor Hz - the motor's nameplate frequency

Motor RPM - the motor's nameplate full-load speed

⁽¹⁾Some package designs employ motors connected for voltages lower (and FLA higher) than the nominal voltage of the package, for improved performance.

6.5 STARTUP OF NEW COMPRESSOR PACKAGE

1. Read and follow all safety warnings and cautions in this manual.
2. At installation ensure:
 - That the incoming power and ground wires are properly connected to terminal blocks in the electrical control box.

6.6 FAULT AND WARNING CODES

The Supervisor constantly monitors drive performance through the serial channel. The following messages are specifically displayed by the Supervisor in the event of problems.

FAULT	POSSIBLE CAUSE	SOLUTION
VSD Param Lim Fault	Incorrect model, HP or Voltage selected in Factory & VSD Setup	Make proper selections.
VSD Com Error	Communications lost with the VSD	Check connections to the VSD. Check VSD control power and check for board faults.
VSD Emergency Stop (VSD Code 51)	Emergency Stop is pressed Break in Estop wiring	Clear the package emergency stop. Check Estop wiring to the drive input.
VSD Com Fault (VSD code 53)	Communications problems detected reported by the VSD	Check connections to the VSD. Check VSD control power and check for board faults.
Drive Fault xx	Problem reported by the VSD	Refer to fault codes in table below.

Drive fault codes are used for least-likely faults. The Supervisor will display these as "Drive Fault" with a code number. If a keypad service tool is plugged into the drive, it will display the fault code and the fault name shown in the first two columns.

CODE	FAULT	POSSIBLE CAUSE	SOLUTION
1	Overcurrent	The variable speed drive has detected a high current (>4xIn) in its output due to: <ul style="list-style-type: none"> • sudden heavy load increase • short in the motor • short in the cables to the motor • unsuitable motor 	Check loading. Check motor. Check cables.
2	Overvoltage	The DC-link voltage has exceeded its high limit due to: <ul style="list-style-type: none"> • too short a deceleration time • high voltage levels or surges in the utility supply 	Make the deceleration time longer. Use a chopper and brake resistor. Correct utility supply voltage (level is too high). Add input impedance to limit surges.

Continued...

- Visually check all power and controls connections to the drive to ensure that no damage has occurred.
3. Check that moisture has not condensed inside the variable speed drive.
 4. Connect to the utility and switch the power on. The Supervisor will establish communications and report errors if correct conditions are not found. If replacing a drive, communication faults will be indicated for either improper communication wiring or improper application or communication software in the drive.
 5. To check rotation, quickly press first the Start  then the Stop  key on the Supervisor. Compressor rotation is factory set. If the fan rotates incorrectly, disconnect power and simply interchange two of the fan motor leads at the fan starter.

Section 6

VARIABLE SPEED DRIVE

CODE	FAULT	POSSIBLE CAUSE	SOLUTION
3	Ground Fault (Earth Fault)	Current sensing indicates that the sum of motor phase currents is not zero. <ul style="list-style-type: none"> insulation failure in motor or motor cables 	Remove faults from ungrounded systems. Check the motor and motor cables.
5	Charging Switch	The charging switch was open when the START command was been given due to: <ul style="list-style-type: none"> faulty operation component failure 	Reset the fault and restart. Should the fault re-occur, contact Sullair service.
6	Emergency stop	An Emergency stop signal was received from one of the digital inputs	Determine the reason for the Emergency stop and remedy it.
7	Saturation trip	<ul style="list-style-type: none"> defective component motor or motor cable short 	Cannot be reset from the keypad. Switch off power. If this fault appears simultaneously with Fault 1, check the motor and motor cables. IF THE PROBLEM IS NOT IN THE MOTOR OR ITS CABLES, DO NOT RE-CONNECT POWER! Contact Sullair service.
8	System fault	<ul style="list-style-type: none"> component failure faulty operation Note: exceptional fault data record, see the Active Fault Menu and Fault Time Data Record for more information	Reset the fault and restart. Should the fault reoccur, contact Sullair service.
9	Undervoltage	DC-link voltage is less than the minimum safe operating voltage limit. <ul style="list-style-type: none"> most probable cause: too low a supply voltage variable speed drive internal fault 	If there was a supply voltage loss or dip, reset the fault and restart the variable speed drive. Check the supply voltage. If it was within specification at the time of the fault, an internal failure has occurred. Contact Sullair service.
10	Input line supervision	Input line phase is low or missing.	Check the utility supply voltage, cables and connections.
11	Output line supervision	Current sensing indicates that there is no current in one motor phase.	Check the motor cables, connections and motor.
13	Under-temperature	Heatsink temperature is under 14°F(-10°C)	Provide supplemental heating or relocate the variable speed drive to a warmer location.
14	Over-temperature	Heatsink temperature is over 194°F(90°C).	An overtemperature warning is issued when the heat sink temperature exceeds 185°F (85°C), a fault occurs at 194°F (90°C). Check for the correct amount and unrestricted flow of cooling air. Check the heatsink for dust or dirt buildup. Check the highest ambient temperature level. Make sure that the switching frequency is not set too high in relation to ambient temperature and motor load.
15	Motor stalled	<ul style="list-style-type: none"> motor or load mechanical failure load is too high stall parameter settings incorrect 	Check motor, mechanical system and load level. Confirm the stall parameter settings.
16	Motor over-temperature	<ul style="list-style-type: none"> motor is overloaded motor overheating has been detected by the variable speed drive motor temperature model 	Decrease the motor load. If no motor overload exists, check the temperature model parameters.
22	EEPROM checksum fault	Parameter save fault <ul style="list-style-type: none"> faulty operation component failure 	Upon reset of this fault, the variable speed drive will automatically reload the parameter default settings. Check all parameter settings after reset. If the fault reoccurs, contact Sullair service.

Continued...


Section 6

VARIABLE SPEED DRIVE

CODE	FAULT	POSSIBLE CAUSE	SOLUTION
24	Counter fault	Values displayed on the counters are incorrect	
25	Microprocessor watchdog fault	<ul style="list-style-type: none"> • faulty operation • component failure 	Reset the fault and restart. Should the fault reoccur, contact Sullair service.
26	Startup prevented	Startup of the drive has been prevented.	Check Start Enable/Interlock settings.
31	IGBT temperature (hardware)	IGBT Inverter Bridge overtemperature protection has detected a high short-term overload current	Check loading. Check motor size.
32	Fan cooling	The variable speed drive cooling fan did not start when commanded	Contact Sullair service.
36	Control Unit	The control unit cannot control the power unit and vice-versa	Change the control unit.
37	Device change (same type)	<ul style="list-style-type: none"> • option board changed • different power rating of drive 	Reset. Note: No Fault Time Data Record is made.
38	Device added (same type)	<ul style="list-style-type: none"> • option board added • drive of different power rating added 	Reset. Note: No Fault Time Data Record is made.
39	Device removed	<ul style="list-style-type: none"> • option board removed • drive removed 	Reset. Note: No Fault Time Data Record is made.
40	Device unknown	Unknown option board or drive	Contact Sullair service.
41	IGBT temperature	IGBT Inverter Bridge overtemperature protection has detected a high short-term overload current	Check loading. Check motor size.
44	Device change (different type)	<ul style="list-style-type: none"> • option board changed • different power rating of drive 	Reset. Note: No Fault Time Data Record is made. Note: Application parameter values restored to default.
45	Device added (different type)	<ul style="list-style-type: none"> • option board added • drive of different power rating added 	Reset. Note: No Fault Time Data Record is made. Note: Application parameter values restored to default.
50	Analog input lin < 4 mA	Current at the analog input is < 4 mA.	Adjust parameter 2.6.1 to "None".
51	External fault	Digital input set as an external fault input has been triggered	Clear the package emergency stop Check Estop wiring to the drive input
53	Communication bus fault	The data connection between the communication bus master and the communication bus board has failed	Check Supervisor bus cable. Set Supervisor VSD to "Serial". If installation is correct contact Sullair service.
54	Slot fault	Defective option board or slot	Check that the board is properly installed and seated in slot. If the installation is correct, contact Sullair service.

NOTES

WORLDWIDE SALES AND SERVICE



SULLAIR ASIA, LTD.

Sullair Road, No. 1
Chiwan, Shekou
Shenzhen, Guangdong PRV.
PRC POST CODE 518068
Telephone: 755-6851686
Fax: 755-6853473
www.sullair-asia.com

SULLAIR EUROPE, S.A.

Zone Des Granges BP 82
42602 Montbrison Cedex, France
Telephone: 33-477968470
Fax: 33-477968499
www.sullaireurope.com

SULLAIR CORPORATION

3700 East Michigan Boulevard
Michigan City, Indiana 46360 U.S.A.

www.sullair.com

Telephone: 1-800-SULLAIR (U.S.A. Only)
or 1-219-879-5451
Fax: (219) 874-1273

PARTS DEPARTMENT

Telephone: 1-888-SULLAIR (U.S.A. Only)
Fax: (219) 874-1835
www.sullair.com

SERVICE DEPARTMENT

Fax: (219) 874-1205
www.sullaircompressors.com

Specifications Subject To
Change Without Prior Notice
E04EP

DEV
Printed in the U.S.A.