

Reset Service Ratiotronic

Press and hold  &  button for 5 seconds.

Press  until you reach the parameter you want

Press  to increase value

Press  to decrease

Maintenance Intervals/Motor

21 Sets the servicing intervals

22 Current setting

23 Confirm service change

Maintenance Intervals/Compressor

24 Sets the servicing intervals

25 Current setting

26 Confirm service change

27 Maintenance fault(1) or warning (0)

For a video copy & paste link

<https://download.boge.com/ssf/s/readFile/share/3385/-3963196458405779380/publicLink/VID-20180417-WA0000.mp4>