

GD Pilot S Reference Sheet

**Gardner
Denver**



Password

Factory 0102

LED Indicators



OK LED – Illuminates when no Warnings or Trips are sensed. Can be in a Ready or Not Ready state. The icon will flash when the machine is running unloaded.




Alert LED – Illuminates when a Warning (flashes) or Trip (constant on) is sensed. Can be in a Ready (warning) or tripped state.



Auto LED – Illuminates when the compressor stops in auto restart.

Buttons



Navigational Buttons – Direction arrows are pressed to navigate. Pressing enter toggles the display between the navigation mode and edit mode.



Not used



Load Button – Puts the compressor into the selected mode of operation. Unit will load if the pressure conditions are right.




Unload Button – Puts the compressor into an unloaded state. Unit will run unloaded indefinitely.




Reset Button – Clears warnings and trips once the connection is corrected.

GD Pilot S Controller T Series Menu Structure

Please refer to the service manual for the machine for additional information on the GD Pilot S controller. There is not a dedicated controller manual for the GD Pilot S controller.




GD Pilot S Controller T Series Menu Structure (continued)



GD Pilot S Controller TVS Series Menu Structure

Please refer to the service manual for the machine for additional information on the GD Pilot S controller. There is not a dedicated controller manual for the GD Pilot S controller.



GD Pilot S Controller TVS Series Menu Structure (continued)

